

| | | | | |
|--------------|---|--------------------------|---|---------------------|
| Sprinter 906 | EZS-Electronic ignition switch | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Live Data | | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Control unit adaptations | Activate drive authorization system. | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Control unit adaptations | Activation(ELV)electric steering lock | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Control unit adaptations | Central Locking (CL/ZV)(Customer-specific settings) | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Control unit adaptations | Key or key track | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Control unit adaptations | Write the VIN. | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Special Functions | Vehicle configuration | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Special Functions | Configuration Electric steering lock | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Special Functions | Configuration Central Locking (CL/ZV) | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Initial startup | Initial start-up(ELV)electric steering lock | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Live Data | | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Special Functions | Central Locking (CL/ZV)(Customer-specific settings) | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Control unit adaptations | Learn transponder key. | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Control unit adaptations | Write the VIN. | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Initial startup | Control module replacement N73 (Electronic Ignition Switch (EIS/EIS) control module) | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Initial startup | Control module replacement N26/S (ES (ELV) control unit) | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | EZS-Electronic ignition switch | Live Data | | V1.00.001 or higher |
| Sprinter 906 | OBF-Upper control panel | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | OBF-Upper control panel | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | OBF-Upper control panel | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | OBF-Upper control panel | Live Data | | V1.00.001 or higher |
| Sprinter 906 | OBF-Upper control panel | Active Test | | V1.00.001 or higher |
| Sprinter 906 | OBF2-Upper control panel | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | OBF2-Upper control panel | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | OBF2-Upper control panel | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | OBF2-Upper control panel | Live Data | | V1.00.001 or higher |
| Sprinter 906 | OBF2-Upper control panel | Active Test | | V1.00.001 or higher |
| Sprinter 906 | SAM-Signal acquisition and actuation module | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | SAM-Signal acquisition and actuation module | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | SAM-Signal acquisition and actuation module | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | SAM-Signal acquisition and actuation module | Live Data | | V1.00.001 or higher |
| Sprinter 906 | SAM-Signal acquisition and actuation module | Active Test | | V1.00.001 or higher |
| Sprinter 906 | ALWR-Headlamp range adjustment | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | ALWR-Headlamp range adjustment | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | ALWR-Headlamp range adjustment | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | ALWR-Headlamp range adjustment | Live Data | | V1.00.001 or higher |
| Sprinter 906 | ALWR-Headlamp range adjustment | Active Test | | V1.00.001 or higher |
| Sprinter 906 | ALWR-Headlamp range adjustment | Control unit adaptations | Calibrate the control module LWR. | V1.00.001 or higher |
| Sprinter 906 | AAG-Trailer connection unit | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | AAG-Trailer connection unit | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | AAG-Trailer connection unit | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | AAG-Trailer connection unit | Live Data | | V1.00.001 or higher |
| Sprinter 906 | AAG-Trailer connection unit | Active Test | | V1.00.001 or higher |
| Sprinter 906 | DBE-Overhead control panel | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | DBE-Overhead control panel | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | DBE-Overhead control panel | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | DBE-Overhead control panel | Live Data | | V1.00.001 or higher |
| Sprinter 906 | DBE-Overhead control panel | Active Test | | V1.00.001 or higher |
| Sprinter 906 | DBE-Overhead control panel | Control unit adaptations | Normalize the component 'SR/SHD (Tilting/Sliding Sunroof)'. Perform denormalization of component SR/SHD (Tilting/Sliding Sunroof). | V1.00.001 or higher |
| Sprinter 906 | DBE-Overhead control panel | Control unit adaptations | Delete denormalization causes. | V1.00.001 or higher |
| Sprinter 906 | DBE-Overhead control panel | Control unit adaptations | Inversion of rotation direction | V1.00.001 or higher |
| Sprinter 906 | DBE-Overhead control panel | Control unit adaptations | Reset alarm sources. | V1.00.001 or higher |
| Sprinter 906 | DBE-Overhead control panel | Control unit adaptations | Teach-in the component 'Battery-operated horn'. | V1.00.001 or higher |
| Sprinter 906 | DBE-Overhead control panel | Control unit adaptations | Teach-in the component 'Rear Light Sensor' | V1.00.001 or higher |
| Sprinter 906 | DBE-Overhead control panel | Control unit adaptations | Function 'Silent alarm' | V1.00.001 or higher |
| Sprinter 906 | KE-Keypress Entry | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | KE-Keypress Entry | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | KE-Keypress Entry | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | KE-Keypress Entry | Live Data | | V1.00.001 or higher |
| Sprinter 906 | KE-Keypress Entry | Active Test | | V1.00.001 or higher |
| Sprinter 906 | ECU Information | | | V1.00.001 or higher |
| Sprinter 906 | MRM-Steering column module | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | MRM-Steering column module | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | MRM-Steering column module | Live Data | | V1.00.001 or higher |
| Sprinter 906 | MRM-Steering column module | Active Test | | V1.00.001 or higher |
| Sprinter 906 | KI-Instrument cluster | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | KI-Instrument cluster | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | KI-Instrument cluster | Live Data | | V1.00.001 or higher |
| Sprinter 906 | KI-Instrument cluster | Active Test | | V1.00.001 or higher |
| Sprinter 906 | KI-Instrument cluster | Oil Reset | | V1.00.001 or higher |
| Sprinter 906 | KI-Instrument cluster | Special Functions | Key-dependent configurations | V1.00.001 or higher |
| Sprinter 906 | KI-Instrument cluster | Special Functions | Coding according to plant data | V1.00.001 or higher |
| Sprinter 906 | KI-Instrument cluster | Control unit adaptations | Reset of maintenance interval display | V1.00.001 or higher |
| Sprinter 906 | PTS-Parktronic system | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | PTS-Parktronic system | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | PTS-Parktronic system | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | PTS-Parktronic system | Live Data | | V1.00.001 or higher |
| Sprinter 906 | PTS-Parktronic system | Active Test | | V1.00.001 or higher |
| Sprinter 906 | PTS-Parktronic system | Special Functions | Customer-specific settings 1 | V1.00.001 or higher |
| Sprinter 906 | PTS-Parktronic system | Special Functions | Customer-specific settings 2 | V1.00.001 or higher |
| Sprinter 906 | PTS-Parktronic system | Special Functions | Customer-specific settings 3 | V1.00.001 or higher |
| Sprinter 906 | MTCD-Modular tachograph | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | MTCD-Modular tachograph | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | MTCD-Modular tachograph | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | MTCD-Modular tachograph | Live Data | | V1.00.001 or higher |
| Sprinter 906 | RADIO Sound 5 | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | RADIO Sound 5 | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | RADIO Sound 5 | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | RADIO Sound 5 | Live Data | | V1.00.001 or higher |
| Sprinter 906 | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | Live Data | | V1.00.001 or higher |
| Sprinter 906 | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | Active Test | | V1.00.001 or higher |
| Sprinter 906 | RADIO Sound 20 | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | RADIO Sound 20 | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | RADIO Sound 20 | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | RADIO Sound 20 | Live Data | | V1.00.001 or higher |
| Sprinter 906 | COMAND or AUDIO | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | COMAND or AUDIO | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | COMAND or AUDIO | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | COMAND or AUDIO | Live Data | | V1.00.001 or higher |
| Sprinter 906 | SOUND SNG | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | SOUND SNG | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | SOUND SNG | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | SOUND SNG | Live Data | | V1.00.001 or higher |
| Sprinter 906 | NAVI-Navigation system (COMAND,SOUND 50) | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | NAVI-Navigation system (COMAND,SOUND 50) | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | NAVI-Navigation system (COMAND,SOUND 50) | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | NAVI-Navigation system (COMAND,SOUND 50) | Live Data | | V1.00.001 or higher |
| Sprinter 906 | CDW-CD changer | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | CDW-CD changer | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | CDW-CD changer | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | CDW-CD changer | Live Data | | V1.00.001 or higher |
| Sprinter 906 | TEL-Telephone control unit | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | TEL-Telephone control unit | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | TEL-Telephone control unit | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | TEL-Telephone control unit | Live Data | | V1.00.001 or higher |
| Sprinter 906 | FSE Hands-free system (Bluetooth) | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | FSE Hands-free system (Bluetooth) | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | FSE Hands-free system (Bluetooth) | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | FSE Hands-free system (Bluetooth) | Live Data | | V1.00.001 or higher |
| Sprinter 906 | FSE Hands-free system (Bluetooth) | Active Test | | V1.00.001 or higher |
| Sprinter 906 | TSG-Door control module front driver side | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | TSG-Door control module front driver side | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | TSG-Door control module front driver side | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | TSG-Door control module front driver side | Live Data | | V1.00.001 or higher |
| Sprinter 906 | TSG-Door control module front driver side | Active Test | | V1.00.001 or higher |
| Sprinter 906 | STL Left electric sliding door | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | STL Left electric sliding door | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | STL Left electric sliding door | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | STL Left electric sliding door | Live Data | | V1.00.001 or higher |
| Sprinter 906 | STL Left electric sliding door | Active Test | | V1.00.001 or higher |
| Sprinter 906 | STR-Right electric sliding door | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | STR-Right electric sliding door | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | STR-Right electric sliding door | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | STR-Right electric sliding door | Live Data | | V1.00.001 or higher |
| Sprinter 906 | STR-Right electric sliding door | Active Test | | V1.00.001 or higher |
| Sprinter 906 | STR-Right electric sliding door | Initial startup | | V1.00.001 or higher |
| Sprinter 906 | KLA-Automatic air conditioning | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | KLA-Automatic air conditioning | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | KLA-Automatic air conditioning | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | KLA-Automatic air conditioning | Live Data | | V1.00.001 or higher |
| Sprinter 906 | KLA-Automatic air conditioning | Active Test | | V1.00.001 or higher |
| Sprinter 906 | PTC-Heater booster | Control unit adaptations | Teach-in the actuator motors. | V1.00.001 or higher |
| Sprinter 906 | PTC-Heater booster | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | PTC-Heater booster | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | PTC-Heater booster | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | PTC-Heater booster | Live Data | | V1.00.001 or higher |
| Sprinter 906 | PTC-Heater booster | Active Test | | V1.00.001 or higher |
| Sprinter 906 | ZHE-Auxiliary heater | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | ZHE-Auxiliary heater | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | ZHE-Auxiliary heater | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | ZHE-Auxiliary heater | Live Data | | V1.00.001 or higher |
| Sprinter 906 | ZHE-Auxiliary heater | Active Test | | V1.00.001 or higher |
| Sprinter 906 | ZHE-Auxiliary heater | Initial startup | | V1.00.001 or higher |
| Sprinter 906 | ZH2-Heater booster | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | ZH2-Heater booster | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | ZH2-Heater booster | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | ZH2-Heater booster | Live Data | | V1.00.001 or higher |
| Sprinter 906 | ZH2-Heater booster | Active Test | | V1.00.001 or higher |
| Sprinter 906 | ZH2-Heater booster | Initial startup | | V1.00.001 or higher |
| Sprinter 906 | PSM-Parameterizable Special Module | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | PSM-Parameterizable Special Module | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | PSM-Parameterizable Special Module | Clear Codes | | V1.00.001 or higher |
| Sprinter 906 | PSM-Parameterizable Special Module | Live Data | | V1.00.001 or higher |
| Sprinter 906 | PSM-Parameterizable Special Module | Active Test | | V1.00.001 or higher |
| Sprinter 906 | ASG-Automatic gearshift system | ECU Information | | V1.00.001 or higher |
| Sprinter 906 | ASG-Automatic gearshift system | Read Codes | | V1.00.001 or higher |
| Sprinter 906 | ASG-Automatic gearshift system | Clear Codes | | V1.00.001 or higher |

| | | | | |
|------------------------------|--|--------------------------|--|---------------------|
| Sprinter VWL73 | ASG-Automatic gearshift system | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | ESP-Electronic stability program | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | ESP-Electronic stability program | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | ESP-Electronic stability program | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | ESP-Electronic stability program | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | ESP-Electronic stability program | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | ESP-Electronic stability program | Control unit adaptations | Calibration of the component 'B24/15 (Yaw rate, lateral and longitudinal acceleration sensor)' | V1.00.001 or higher |
| Sprinter VWL73 | RDK Tire pressure monitor(Ups to model year 2010) | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | RDK Tire pressure monitor(Ups to model year 2010) | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | RDK Tire pressure monitor(Ups to model year 2010) | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | RDK Tire pressure monitor(Ups to model year 2010) | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | RDK Tire pressure monitor(Ups to model year 2010) | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | RDK Tire pressure monitor(Ups to model year 2010) | Special Functions | Initial start-up with automatic takeover of settings from the old control module | V1.00.001 or higher |
| Sprinter VWL73 | RDK Tire pressure monitor(Ups to model year 2010) | Special Functions | Initial start-up with manual settings input for new control module.For example: The previous control module cannot be read any longer. | V1.00.001 or higher |
| Sprinter VWL73 | RDK Tire pressure monitor(Ups to model year 2010) | Special Functions | Write the wheel electronics ID number. | V1.00.001 or higher |
| Sprinter VWL73 | SRS supplemental restraint system | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | SRS supplemental restraint system | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | SRS supplemental restraint system | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | SRS supplemental restraint system | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | SRS supplemental restraint system | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | SRS supplemental restraint system | Control unit adaptations | Interlock control module. | V1.00.001 or higher |
| Sprinter VWL73 | SRS supplemental restraint system | Special Functions | Read the coding. | V1.00.001 or higher |
| Sprinter VWL73 | SRS supplemental restraint system | Special Functions | | V1.00.001 or higher |
| Sprinter VWL73 | EZS-Electronic Ignition switch | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | EZS-Electronic Ignition switch | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | EZS-Electronic Ignition switch | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | EZS-Electronic Ignition switch | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | EZS-Electronic Ignition switch | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | OFB-Upper control panel | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | OFB-Upper control panel | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | OFB-Upper control panel | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | OFB-Upper control panel | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | OFB-Upper control panel | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | SAM-Signal acquisition and actuation module | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | SAM-Signal acquisition and actuation module | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | SAM-Signal acquisition and actuation module | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | SAM-Signal acquisition and actuation module | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | SAM-Signal acquisition and actuation module | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | AAG-Trailer connection unit | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | AAG-Trailer connection unit | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | AAG-Trailer connection unit | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | AAG-Trailer connection unit | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | AAG-Trailer connection unit | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | DBE-Overhead control panel | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | DBE-Overhead control panel | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | DBE-Overhead control panel | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | DBE-Overhead control panel | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | DBE-Overhead control panel | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | DBE-Overhead control panel | Control unit adaptations | Normalize the component 'SR/SHD (Tilting/Sliding Sunroof)' | V1.00.001 or higher |
| Sprinter VWL73 | DBE-Overhead control panel | Control unit adaptations | Perform denormalization of component SR/SHD (Tilting/Sliding Sunroof). | V1.00.001 or higher |
| Sprinter VWL73 | DBE-Overhead control panel | Control unit adaptations | Delete denormalization cause. | V1.00.001 or higher |
| Sprinter VWL73 | DBE-Overhead control panel | Control unit adaptations | Inversion of rotation direction | V1.00.001 or higher |
| Sprinter VWL73 | DBE-Overhead control panel | Control unit adaptations | Reset alarm sources. | V1.00.001 or higher |
| Sprinter VWL73 | DBE-Overhead control panel | Control unit adaptations | Teach-in the component 'Battery operated horn'. | V1.00.001 or higher |
| Sprinter VWL73 | DBE-Overhead control panel | Control unit adaptations | Teach-in the component 'Rain/Light Sensor'. | V1.00.001 or higher |
| Sprinter VWL73 | DBE-Overhead control panel | Control unit adaptations | Function 'Silent alarm' | V1.00.001 or higher |
| Sprinter VWL73 | MMB-Steering column module | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | MMB-Steering column module | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | MMB-Steering column module | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | MMB-Steering column module | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | MMB-Steering column module | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | KI-Instrument cluster | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | KI-Instrument cluster | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | KI-Instrument cluster | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | KI-Instrument cluster | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | KI-Instrument cluster | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | KI-Instrument cluster | Clear Reset | | V1.00.001 or higher |
| Sprinter VWL73 | KI-Instrument cluster | Special Functions | Key-dependent configurations | V1.00.001 or higher |
| Sprinter VWL73 | KI-Instrument cluster | Special Functions | Reset according to plant data | V1.00.001 or higher |
| Sprinter VWL73 | KI-Instrument cluster | Control unit adaptations | Reset of maintenance interval display | V1.00.001 or higher |
| Sprinter VWL73 | MTCO-Modular tachograph | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | MTCO-Modular tachograph | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | MTCO-Modular tachograph | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | MTCO-Modular tachograph | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | PTS-Parktronic system | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | PTS-Parktronic system | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | PTS-Parktronic system | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | PTS-Parktronic system | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | PTS-Parktronic system | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | PTS-Parktronic system | Special Functions | Customer-specific settings 1 | V1.00.001 or higher |
| Sprinter VWL73 | PTS-Parktronic system | Special Functions | Customer-specific settings 2 | V1.00.001 or higher |
| Sprinter VWL73 | PTS-Parktronic system | Special Functions | Customer-specific settings 3 | V1.00.001 or higher |
| Sprinter VWL73 | FSE Hands-free system (Bluetooth) | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | FSE Hands-free system (Bluetooth) | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | FSE Hands-free system (Bluetooth) | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | FSE Hands-free system (Bluetooth) | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | FSE Hands-free system (Bluetooth) | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | AGW-Audio gateway (IMDSI network management, diagnosis gateway, radio tuner) | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | AGW-Audio gateway (IMDSI network management, diagnosis gateway, radio tuner) | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | AGW-Audio gateway (IMDSI network management, diagnosis gateway, radio tuner) | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | AGW-Audio gateway (IMDSI network management, diagnosis gateway, radio tuner) | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | RADIO Sound 20 | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | RADIO Sound 20 | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | RADIO Sound 20 | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | RADIO Sound 20 | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | COMMAND or AUDIO | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | COMMAND or AUDIO | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | COMMAND or AUDIO | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | COMMAND or AUDIO | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | COMMAND or AUDIO | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | RADIO Sound 5 | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | RADIO Sound 5 | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | RADIO Sound 5 | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | SOUND SNG | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | SOUND SNG | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | SOUND SNG | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | SOUND SNG | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | SOUND SNG | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | NAVI-Navigation system (COMMAND,SOUND 50) | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | NAVI-Navigation system (COMMAND,SOUND 50) | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | NAVI-Navigation system (COMMAND,SOUND 50) | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | NAVI-Navigation system (COMMAND,SOUND 50) | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | NAVI-Navigation system (COMMAND,SOUND 50) | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | CDW-CD charger | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | CDW-CD charger | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | CDW-CD charger | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | CDW-CD charger | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | TEL-Telephone control unit | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | TEL-Telephone control unit | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | TEL-Telephone control unit | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | TEL-Telephone control unit | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | TSG-Door control module front driver side | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | TSG-Door control module front driver side | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | TSG-Door control module front driver side | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | TSG-Door control module front driver side | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | TSG-Door control module front driver side | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | KLA-Automatic air conditioning | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | KLA-Automatic air conditioning | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | KLA-Automatic air conditioning | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | KLA-Automatic air conditioning | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | KLA-Automatic air conditioning | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | KLA-Automatic air conditioning | Control unit adaptations | Teach-in the actuator motors. | V1.00.001 or higher |
| Sprinter VWL73 | PFC-Heater booster | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | PFC-Heater booster | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | PFC-Heater booster | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | PFC-Heater booster | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | PFC-Heater booster | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | ZHE-Auxiliary heater | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | ZHE-Auxiliary heater | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | ZHE-Auxiliary heater | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | ZHE-Auxiliary heater | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | ZHE-Auxiliary heater | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | ZHE-Auxiliary heater | Initial startup | | V1.00.001 or higher |
| Sprinter VWL73 | ZH2-Heater booster | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | ZH2-Heater booster | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | ZH2-Heater booster | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | ZH2-Heater booster | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | ZH2-Heater booster | Active Test | | V1.00.001 or higher |
| Sprinter VWL73 | ZH2-Heater booster | Initial startup | | V1.00.001 or higher |
| Sprinter VWL73 | PSM-Parameterizable Special Module | ECU Information | | V1.00.001 or higher |
| Sprinter VWL73 | PSM-Parameterizable Special Module | Read Codes | | V1.00.001 or higher |
| Sprinter VWL73 | PSM-Parameterizable Special Module | Clear Codes | | V1.00.001 or higher |
| Sprinter VWL73 | PSM-Parameterizable Special Module | Live Data | | V1.00.001 or higher |
| Sprinter VWL73 | PSM-Parameterizable Special Module | Active Test | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | CR-Common rail | ECU Information | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | CR-Common rail | Read Codes | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | CR-Common rail | Clear Codes | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | CR-Common rail | Live Data | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | CR-Common rail | Active Test | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | CR-Common rail | Special Functions | Variant coding | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | CR-Common rail | Special Functions | Interlock control module. | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | CR-Common rail | Special Functions | Injector classification | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | CR-Common rail | Read Codes | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | CR-Common rail | Clear Codes | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | CR-Common rail | Live Data | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | CR-Common rail | Active Test | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | CR-Common rail | Control unit adaptations | Injector classification | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | CR-Common rail | Special Functions | Activate the control module 'CDI'. | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | ME-Motor electronics | ECU Information | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | ME-Motor electronics | Read Codes | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | ME-Motor electronics | Clear Codes | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | ME-Motor electronics | Live Data | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | ME-Motor electronics | Active Test | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | ME-Motor electronics | Control unit adaptations | Interlock control module. | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | ME-Motor electronics | Special Functions | Variant coding | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | ME-Motor electronics | Special Functions | Automatic control module replacement | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | ME-Motor electronics | Special Functions | Maximum vehicle speed limit(EG) | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | LPG Liquefied Petroleum Gas | ECU Information | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | LPG Liquefied Petroleum Gas | Read Codes | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | LPG Liquefied Petroleum Gas | Clear Codes | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | LPG Liquefied Petroleum Gas | Live Data | | V1.00.001 or higher |
| Sprinter 901/902/903/904/905 | LPG Liquefied Petroleum Gas | Special Functions | Automatic control module replacement | V1.00.001 or higher |

| | | | | |
|----------------------------|--------------------------------------|--------------------------|--|---------------------|
| Sprinter YD.../WD.../XD... | APS-Auto pilot system | ECU Information | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | APS-Auto pilot system | Read Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | APS-Auto pilot system | Clear Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | APS-Auto pilot system | Live Data | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ARS-All-wheel system | ECU Information | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ARS-All-wheel system | Read Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ARS-All-wheel system | Clear Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ARS-All-wheel system | Live Data | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | EDW2-Anti-theft alarm | ECU Information | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | EDW2-Anti-theft alarm | Read Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | EDW2-Anti-theft alarm | Clear Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | EDW2-Anti-theft alarm | Live Data | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | EDW2-Anti-theft alarm | Active Test | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | EDW2-Anti-theft alarm | Control unit adaptations | Alarm sources | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | EWM-Electronic selector lever module | ECU Information | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | EWM-Electronic selector lever module | Read Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | EWM-Electronic selector lever module | Clear Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | EWM-Electronic selector lever module | Live Data | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | EWM-Electronic selector lever module | Active Test | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | HZR-Heating control | ECU Information | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | HZR-Heating control | Read Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | HZR-Heating control | Clear Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | HZR-Heating control | Live Data | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | HZR-Heating control | Active Test | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | RHF Backup assist | ECU Information | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | RHF Backup assist | Read Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | RHF Backup assist | Clear Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | RHF Backup assist | Live Data | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | RHF Backup assist | Active Test | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | RHF Backup assist | Control unit adaptations | Parameterization | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZV-Central locking system | ECU Information | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZV-Central locking system | Read Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZV-Central locking system | Clear Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZV-Central locking system | Live Data | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZV-Central locking system | Active Test | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | Radio (SOUND series) | ECU Information | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | Radio (SOUND series) | Read Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | Radio (SOUND series) | Clear Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | Radio (SOUND series) | Live Data | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | AUDIO/APS Auto pilot system | ECU Information | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | AUDIO/APS Auto pilot system | Read Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | AUDIO/APS Auto pilot system | Clear Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | AUDIO/APS Auto pilot system | Live Data | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZHE-4-Auxiliary heater warm air | ECU Information | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZHE-4-Auxiliary heater warm air | Read Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZHE-4-Auxiliary heater warm air | Clear Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZHE-4-Auxiliary heater warm air | Live Data | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZHE-4-Auxiliary heater warm air | Active Test | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZJH-Heater booster | ECU Information | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZJH-Heater booster | Read Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZJH-Heater booster | Clear Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZJH-Heater booster | Live Data | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZJH-Heater booster | Active Test | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZHE-Auxiliary heater | ECU Information | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZHE-Auxiliary heater | Read Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZHE-Auxiliary heater | Clear Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZHE-Auxiliary heater | Live Data | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | ZHE-Auxiliary heater | Active Test | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | AB-Airbag | ECU Information | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | AB-Airbag | Read Codes | | V1.00.001 or higher |
| Sprinter YD.../WD.../XD... | AB-Airbag | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | CR-Common rail | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | CR-Common rail | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | CR-Common rail | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | CR-Common rail | Live Data | | V1.00.001 or higher |
| Sprinter 690 | CR-Common rail | Active Test | | V1.00.001 or higher |
| Sprinter 690 | CR-Common rail | Special Functions | Variant coding | V1.00.001 or higher |
| Sprinter 690 | CR-Common rail | Special Functions | Interlock control module. | V1.00.001 or higher |
| Sprinter 690 | CR-Common rail | Special Functions | Injector classification | V1.00.001 or higher |
| Sprinter 690 | CR-Common rail | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | CR-Common rail | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | CR-Common rail | Live Data | | V1.00.001 or higher |
| Sprinter 690 | CR-Common rail | Active Test | | V1.00.001 or higher |
| Sprinter 690 | CR-Common rail | Control unit adaptations | Injector classification | V1.00.001 or higher |
| Sprinter 690 | CR-Common rail | Special Functions | Activate the control module 'CDI'. | V1.00.001 or higher |
| Sprinter 690 | ME-Motor electronics | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | ME-Motor electronics | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | ME-Motor electronics | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | ME-Motor electronics | Live Data | | V1.00.001 or higher |
| Sprinter 690 | ME-Motor electronics | Active Test | | V1.00.001 or higher |
| Sprinter 690 | ME-Motor electronics | Control unit adaptations | Interlock control module. | V1.00.001 or higher |
| Sprinter 690 | ME-Motor electronics | Special Functions | Variant coding | V1.00.001 or higher |
| Sprinter 690 | ME-Motor electronics | Special Functions | Automatic control module replacement | V1.00.001 or higher |
| Sprinter 690 | ME-Motor electronics | Special Functions | Maximum vehicle speed limit(HBG) | V1.00.001 or higher |
| Sprinter 690 | LPG Liquefied Petroleum Gas | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | LPG Liquefied Petroleum Gas | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | LPG Liquefied Petroleum Gas | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | LPG Liquefied Petroleum Gas | Live Data | | V1.00.001 or higher |
| Sprinter 690 | LPG Liquefied Petroleum Gas | Special Functions | Automatic control module replacement | V1.00.001 or higher |
| Sprinter 690 | SSG-Spritzshift transmission | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | SSG-Spritzshift transmission | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | SSG-Spritzshift transmission | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | SSG-Spritzshift transmission | Live Data | | V1.00.001 or higher |
| Sprinter 690 | SSG-Spritzshift transmission | Active Test | | V1.00.001 or higher |
| Sprinter 690 | SSG-Spritzshift transmission | Control unit adaptations | Learn gears. | V1.00.001 or higher |
| Sprinter 690 | SSG-Spritzshift transmission | Control unit adaptations | Learn clutch. | V1.00.001 or higher |
| Sprinter 690 | SSG-Spritzshift transmission | Special Functions | Automatic control module replacement | V1.00.001 or higher |
| Sprinter 690 | ESP-Electronic stability program | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | ESP-Electronic stability program | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | ESP-Electronic stability program | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | ESP-Electronic stability program | Live Data | | V1.00.001 or higher |
| Sprinter 690 | ESP-Electronic stability program | Active Test | | V1.00.001 or higher |
| Sprinter 690 | ESP-Electronic stability program | Control unit adaptations | Component 'B248 (Steering Angle Sensor (SAS)) - Please calibrate. | V1.00.001 or higher |
| Sprinter 690 | ESP-Electronic stability program | Control unit adaptations | Calibration of the Steering Angle Sensor (SAS) | V1.00.001 or higher |
| Sprinter 690 | ESP-Electronic stability program | Special Functions | Coding/Vehicle length | V1.00.001 or higher |
| Sprinter 690 | ESP-Electronic stability program | Special Functions | Parameterization of Hydraulic brake assist (Read only - cannot be changed) | V1.00.001 or higher |
| Sprinter 690 | ESP-Electronic stability program | Special Functions | Parameterization | V1.00.001 or higher |
| Sprinter 690 | ESP-Electronic stability program | Special Functions | Automatic control module replacement | V1.00.001 or higher |
| Sprinter 690 | ESP-Electronic stability program | Special Functions | Coding according to plant data | V1.00.001 or higher |
| Sprinter 690 | ABS-Anti lock braking system | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | ABS-Anti lock braking system | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | ABS-Anti lock braking system | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | ABS-Anti lock braking system | Live Data | | V1.00.001 or higher |
| Sprinter 690 | ABS-Anti lock braking system | Active Test | | V1.00.001 or higher |
| Sprinter 690 | ABS-Anti lock braking system | Special Functions | | V1.00.001 or higher |
| Sprinter 690 | KI-Instrument cluster | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | KI-Instrument cluster | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | KI-Instrument cluster | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | KI-Instrument cluster | Live Data | | V1.00.001 or higher |
| Sprinter 690 | KI-Instrument cluster | Active Test | | V1.00.001 or higher |
| Sprinter 690 | KI-Instrument cluster | Oil Reset | | V1.00.001 or higher |
| Sprinter 690 | KI-Instrument cluster | Control unit adaptations | Setting the main odometer back | V1.00.001 or higher |
| Sprinter 690 | KI-Instrument cluster | Special Functions | General parameter set | V1.00.001 or higher |
| Sprinter 690 | KI-Instrument cluster | Special Functions | Set the time. | V1.00.001 or higher |
| Sprinter 690 | KI-Instrument cluster | Special Functions | Set tire size. | V1.00.001 or higher |
| Sprinter 690 | KI-Instrument cluster | Special Functions | Setting the main odometer back | V1.00.001 or higher |
| Sprinter 690 | KI-Instrument cluster | Special Functions | Manual replacement of control module | V1.00.001 or higher |
| Sprinter 690 | WSP-Immobilizer | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | WSP-Immobilizer | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | WSP-Immobilizer | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | WSP-Immobilizer | Live Data | | V1.00.001 or higher |
| Sprinter 690 | WSP-Immobilizer | Control unit adaptations | Learn transponder key. | V1.00.001 or higher |
| Sprinter 690 | WSP-Immobilizer | Control unit adaptations | TEMIC transponder | V1.00.001 or higher |
| Sprinter 690 | APS-Auto pilot system | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | APS-Auto pilot system | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | APS-Auto pilot system | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | APS-Auto pilot system | Live Data | | V1.00.001 or higher |
| Sprinter 690 | ARS-All-wheel system | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | ARS-All-wheel system | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | ARS-All-wheel system | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | ARS-All-wheel system | Live Data | | V1.00.001 or higher |
| Sprinter 690 | ARS-All-wheel system | Active Test | | V1.00.001 or higher |
| Sprinter 690 | EDW2-Anti-theft alarm | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | EDW2-Anti-theft alarm | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | EDW2-Anti-theft alarm | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | EDW2-Anti-theft alarm | Live Data | | V1.00.001 or higher |
| Sprinter 690 | EDW2-Anti-theft alarm | Active Test | | V1.00.001 or higher |
| Sprinter 690 | EDW2-Anti-theft alarm | Control unit adaptations | Alarm sources | V1.00.001 or higher |
| Sprinter 690 | EWM-Electronic selector lever module | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | EWM-Electronic selector lever module | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | EWM-Electronic selector lever module | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | EWM-Electronic selector lever module | Live Data | | V1.00.001 or higher |
| Sprinter 690 | EWM-Electronic selector lever module | Active Test | | V1.00.001 or higher |
| Sprinter 690 | HZR-Heating control | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | HZR-Heating control | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | HZR-Heating control | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | HZR-Heating control | Live Data | | V1.00.001 or higher |
| Sprinter 690 | HZR-Heating control | Active Test | | V1.00.001 or higher |
| Sprinter 690 | RHF Backup assist | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | RHF Backup assist | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | RHF Backup assist | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | RHF Backup assist | Live Data | | V1.00.001 or higher |
| Sprinter 690 | RHF Backup assist | Active Test | | V1.00.001 or higher |
| Sprinter 690 | RHF Backup assist | Control unit adaptations | Parameterization | V1.00.001 or higher |
| Sprinter 690 | ZV-Central locking system | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | ZV-Central locking system | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | ZV-Central locking system | Live Data | | V1.00.001 or higher |
| Sprinter 690 | ZV-Central locking system | Active Test | | V1.00.001 or higher |
| Sprinter 690 | ZV-Central locking system | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | Radio (SOUND series) | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | Radio (SOUND series) | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | Radio (SOUND series) | Live Data | | V1.00.001 or higher |
| Sprinter 690 | Radio (SOUND series) | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | AUDIO/APS Auto pilot system | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | AUDIO/APS Auto pilot system | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | AUDIO/APS Auto pilot system | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | AUDIO/APS Auto pilot system | Live Data | | V1.00.001 or higher |

| | | | | |
|--------------|---|--------------------------|---|---------------------|
| Sprinter 690 | ZHE 4-Auxiliary heater warm air | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | ZHE 4-Auxiliary heater warm air | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | ZHE 4-Auxiliary heater warm air | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | ZHE 4-Auxiliary heater warm air | Live Data | | V1.00.001 or higher |
| Sprinter 690 | ZHE 4-Auxiliary heater warm air | Active Test | | V1.00.001 or higher |
| Sprinter 690 | ZUH Heater booster | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | ZUH Heater booster | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | ZUH Heater booster | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | ZUH Heater booster | Live Data | | V1.00.001 or higher |
| Sprinter 690 | ZUH Heater booster | Active Test | | V1.00.001 or higher |
| Sprinter 690 | ZHE-Auxiliary heater | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | ZHE-Auxiliary heater | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | ZHE-Auxiliary heater | Clear Codes | | V1.00.001 or higher |
| Sprinter 690 | ZHE-Auxiliary heater | Live Data | | V1.00.001 or higher |
| Sprinter 690 | ZHE-Auxiliary heater | Active Test | | V1.00.001 or higher |
| Sprinter 690 | AB-Airbag | ECU Information | | V1.00.001 or higher |
| Sprinter 690 | AB-Airbag | Read Codes | | V1.00.001 or higher |
| Sprinter 690 | AB-Airbag | Clear Codes | | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | ECU Information | | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Read Codes | | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Clear Codes | | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Live Data | | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Active Test | | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Diesel Particulate Filter | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Initialization after component replacement | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Drive authorization | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Write the VIN. | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Control unit adaptations | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Functions in combination with control unit PSM | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Maximum vehicle speed limit | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Initialization of system 'Diesel Particulate Filter' | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Teach-in the used Diesel Particulate Filter (DPF) | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Regeneration of the Diesel Particulate Filter (DPF) | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Regeneration of the Diesel Particulate Filter (DPF) when driving | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Adjustment of the injector injection quantities | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Initialization of system 'Air filter' | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Initialization of system 'Throttle valve positioner' | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Initialization of system 'Air intake, turbocharging' | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Control unit adaptations | Initialization of system 'Common Rail' | V1.00.001 or higher |
| Sprinter 909 | CD4-Common Rail Diesel Injection | Special Functions | Coding according to plant data | V1.00.001 or higher |
| Sprinter 909 | ESP-Electronic stability program | ECU Information | | V1.00.001 or higher |
| Sprinter 909 | ESP-Electronic stability program | Read Codes | | V1.00.001 or higher |
| Sprinter 909 | ESP-Electronic stability program | Clear Codes | | V1.00.001 or higher |
| Sprinter 909 | ESP-Electronic stability program | Live Data | | V1.00.001 or higher |
| Sprinter 909 | ESP-Electronic stability program | Active Test | | V1.00.001 or higher |
| Sprinter 909 | ESP-Electronic stability program | Control unit adaptations | Calibration of the component 'Sensor 'yaw rate, lateral and longitudinal acceleration'' | V1.00.001 or higher |
| Sprinter 909 | ESP-Electronic stability program | Control unit adaptations | Calibration of the component 'B143 (Steering angle sensor)' | V1.00.001 or higher |
| Sprinter 909 | SRS-supplemental restraint system | ECU Information | | V1.00.001 or higher |
| Sprinter 909 | SRS-supplemental restraint system | Read Codes | | V1.00.001 or higher |
| Sprinter 909 | SRS-supplemental restraint system | Clear Codes | | V1.00.001 or higher |
| Sprinter 909 | SRS-supplemental restraint system | Live Data | | V1.00.001 or higher |
| Sprinter 909 | SRS-supplemental restraint system | Active Test | | V1.00.001 or higher |
| Sprinter 909 | SRS-supplemental restraint system | Control unit adaptations | Interlock control module. | V1.00.001 or higher |
| Sprinter 909 | HZR-Heating control | ECU Information | | V1.00.001 or higher |
| Sprinter 909 | HZR-Heating control | Read Codes | | V1.00.001 or higher |
| Sprinter 909 | HZR-Heating control | Clear Codes | | V1.00.001 or higher |
| Sprinter 909 | HZR-Heating control | Live Data | | V1.00.001 or higher |
| Sprinter 909 | HZR-Heating control | Active Test | | V1.00.001 or higher |
| Sprinter 909 | WSP-immobilizer | ECU Information | | V1.00.001 or higher |
| Sprinter 909 | WSP-immobilizer | Read Codes | | V1.00.001 or higher |
| Sprinter 909 | WSP-immobilizer | Clear Codes | | V1.00.001 or higher |
| Sprinter 909 | WSP-immobilizer | Live Data | | V1.00.001 or higher |
| Sprinter 909 | WSP-immobilizer | Control unit adaptations | Learn additional transponder key (X1) | V1.00.001 or higher |
| Sprinter 909 | WSP-immobilizer | Control unit adaptations | Erase all the transponder keys and relearn the current one (X2) | V1.00.001 or higher |
| Sprinter 909 | ZV-Central locking system | ECU Information | | V1.00.001 or higher |
| Sprinter 909 | ZV-Central locking system | Read Codes | | V1.00.001 or higher |
| Sprinter 909 | ZV-Central locking system | Clear Codes | | V1.00.001 or higher |
| Sprinter 909 | ZV-Central locking system | Live Data | | V1.00.001 or higher |
| Sprinter 909 | ZV-Central locking system | Active Test | | V1.00.001 or higher |
| Sprinter 909 | KI-Instrument cluster | ECU Information | | V1.00.001 or higher |
| Sprinter 909 | KI-Instrument cluster | Read Codes | | V1.00.001 or higher |
| Sprinter 909 | KI-Instrument cluster | Clear Codes | | V1.00.001 or higher |
| Sprinter 909 | KI-Instrument cluster | Live Data | | V1.00.001 or higher |
| Sprinter 909 | KI-Instrument cluster | Active Test | | V1.00.001 or higher |
| Sprinter 909 | KI-Instrument cluster | Control unit adaptations | Set the time. | V1.00.001 or higher |
| Sprinter 909 | KI-Instrument cluster | Control unit adaptations | Set tire size. | V1.00.001 or higher |
| Vaneo | ACS-Automatic clutch system | ECU Information | | V1.00.001 or higher |
| Vaneo | ACS-Automatic clutch system | Read Codes | | V1.00.001 or higher |
| Vaneo | ACS-Automatic clutch system | Clear Codes | | V1.00.001 or higher |
| Vaneo | ACS-Automatic clutch system | Live Data | | V1.00.001 or higher |
| Vaneo | ACS-Automatic clutch system | Active Test | | V1.00.001 or higher |
| Vaneo | ACS-Automatic clutch system | Control unit adaptations | Bleeding | V1.00.001 or higher |
| Vaneo | ACS-Automatic clutch system | Control unit adaptations | AIS setting | V1.00.001 or higher |
| Vaneo | ACS-Automatic clutch system | Control unit adaptations | Engagement point determination | V1.00.001 or higher |
| Vaneo | AUDIO/APS-Auto pilot system | ECU Information | | V1.00.001 or higher |
| Vaneo | AUDIO/APS-Auto pilot system | Read Codes | | V1.00.001 or higher |
| Vaneo | AUDIO/APS-Auto pilot system | Clear Codes | | V1.00.001 or higher |
| Vaneo | AUDIO/APS-Auto pilot system | Live Data | | V1.00.001 or higher |
| Vaneo | AUDIO/APS-Auto pilot system | Active Test | | V1.00.001 or higher |
| Vaneo | CDC-CD changer | ECU Information | | V1.00.001 or higher |
| Vaneo | CDC-CD changer | Read Codes | | V1.00.001 or higher |
| Vaneo | CDC-CD changer | Clear Codes | | V1.00.001 or higher |
| Vaneo | COMAND | ECU Information | | V1.00.001 or higher |
| Vaneo | COMAND | Read Codes | | V1.00.001 or higher |
| Vaneo | COMAND | Clear Codes | | V1.00.001 or higher |
| Vaneo | COMAND | Live Data | | V1.00.001 or higher |
| Vaneo | ATA-Anti-theft alarm system | ECU Information | | V1.00.001 or higher |
| Vaneo | ATA-Anti-theft alarm system | Read Codes | | V1.00.001 or higher |
| Vaneo | ATA-Anti-theft alarm system | Clear Codes | | V1.00.001 or higher |
| Vaneo | ATA-Anti-theft alarm system | Live Data | | V1.00.001 or higher |
| Vaneo | ATA-Anti-theft alarm system | Active Test | | V1.00.001 or higher |
| Vaneo | ESP-Electronic stability program | ECU Information | | V1.00.001 or higher |
| Vaneo | ESP-Electronic stability program | Read Codes | | V1.00.001 or higher |
| Vaneo | ESP-Electronic stability program | Clear Codes | | V1.00.001 or higher |
| Vaneo | ESP-Electronic stability program | Live Data | | V1.00.001 or higher |
| Vaneo | ESP-Electronic stability program | Active Test | | V1.00.001 or higher |
| Vaneo | ESM-Electronic selector module | Control unit adaptations | Road test | V1.00.001 or higher |
| Vaneo | ESM-Electronic selector module | ECU Information | | V1.00.001 or higher |
| Vaneo | ESM-Electronic selector module | Read Codes | | V1.00.001 or higher |
| Vaneo | ESM-Electronic selector module | Clear Codes | | V1.00.001 or higher |
| Vaneo | ESM-Electronic selector module | Live Data | | V1.00.001 or higher |
| Vaneo | ESM-Electronic selector module | Active Test | | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | ECU Information | | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | Read Codes | | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | Clear Codes | | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | Live Data | | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | Active Test | | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | Control unit adaptations | Reset touch-in byte for the air conditioning or automatic heater. | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | Control unit adaptations | Adaptation | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | Control unit adaptations | Diagnosis routines | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | Special Functions | Control module replacement | V1.00.001 or higher |
| Vaneo | DAS-Drive authorization system | ECU Information | | V1.00.001 or higher |
| Vaneo | DAS-Drive authorization system | Read Codes | | V1.00.001 or higher |
| Vaneo | DAS-Drive authorization system | Clear Codes | | V1.00.001 or higher |
| Vaneo | DAS-Drive authorization system | Live Data | | V1.00.001 or higher |
| Vaneo | DAS-Drive authorization system | Active Test | | V1.00.001 or higher |
| Vaneo | DAS-Drive authorization system | Control unit adaptations | VIN | V1.00.001 or higher |
| Vaneo | DAS-Drive authorization system | Control unit adaptations | Inhibit or re-authorize key. | V1.00.001 or higher |
| Vaneo | IC-Instrument cluster | ECU Information | | V1.00.001 or higher |
| Vaneo | IC-Instrument cluster | Read Codes | | V1.00.001 or higher |
| Vaneo | IC-Instrument cluster | Clear Codes | | V1.00.001 or higher |
| Vaneo | IC-Instrument cluster | Live Data | | V1.00.001 or higher |
| Vaneo | IC-Instrument cluster | Active Test | | V1.00.001 or higher |
| Vaneo | IC-Instrument cluster | Oil Reset | | V1.00.001 or higher |
| Vaneo | IC-Instrument cluster | Control unit adaptations | Instrument Cluster (IC) settings | V1.00.001 or higher |
| Vaneo | IC-Instrument cluster | Control unit adaptations | ASSYST settings | V1.00.001 or higher |
| Vaneo | IC-Instrument cluster | Special Functions | Read the coding and transmit to the new control module. | V1.00.001 or higher |
| Vaneo | IC-Instrument cluster | Special Functions | Read the coding and change as necessary. | V1.00.001 or higher |
| Vaneo | HEAT/FAC-Automatic temperature control | ECU Information | | V1.00.001 or higher |
| Vaneo | HEAT/FAC-Automatic temperature control | Read Codes | | V1.00.001 or higher |
| Vaneo | HEAT/FAC-Automatic temperature control | Clear Codes | | V1.00.001 or higher |
| Vaneo | HEAT/FAC-Automatic temperature control | Live Data | | V1.00.001 or higher |
| Vaneo | HEAT/FAC-Automatic temperature control | Active Test | | V1.00.001 or higher |
| Vaneo | ECM-Engine control monolith | ECU Information | | V1.00.001 or higher |
| Vaneo | ECM-Engine control monolith | Read Codes | | V1.00.001 or higher |
| Vaneo | ECM-Engine control monolith | Clear Codes | | V1.00.001 or higher |
| Vaneo | ECM-Engine control monolith | Live Data | | V1.00.001 or higher |
| Vaneo | ECM-Engine control monolith | Active Test | | V1.00.001 or higher |
| Vaneo | ECM-Engine control monolith | Special Functions | Variant coding | V1.00.001 or higher |
| Vaneo | ECM-Engine control monolith | Special Functions | Default installation | V1.00.001 or higher |
| Vaneo | ECM-Engine control monolith | Special Functions | Correction programming | V1.00.001 or higher |
| Vaneo | PFS-Parktronic system | ECU Information | | V1.00.001 or higher |
| Vaneo | PFS-Parktronic system | Read Codes | | V1.00.001 or higher |
| Vaneo | PFS-Parktronic system | Clear Codes | | V1.00.001 or higher |
| Vaneo | PFS-Parktronic system | Live Data | | V1.00.001 or higher |
| Vaneo | PFS-Parktronic system | Active Test | | V1.00.001 or higher |
| Vaneo | Radio (SOUND series) | ECU Information | | V1.00.001 or higher |
| Vaneo | Radio (SOUND series) | Read Codes | | V1.00.001 or higher |
| Vaneo | Radio (SOUND series) | Clear Codes | | V1.00.001 or higher |
| Vaneo | Radio (SOUND series) | Live Data | | V1.00.001 or higher |
| Vaneo | ZHE-Auxiliary heater | ECU Information | | V1.00.001 or higher |
| Vaneo | ZHE-Auxiliary heater | Read Codes | | V1.00.001 or higher |
| Vaneo | ZHE-Auxiliary heater | Clear Codes | | V1.00.001 or higher |
| Vaneo | ZHE-Auxiliary heater | Live Data | | V1.00.001 or higher |
| Vaneo | ZHE-Auxiliary heater | Active Test | | V1.00.001 or higher |
| Vaneo | CTEL-Cellular telephone 1 (fixed installation or portable)(D28) | ECU Information | | V1.00.001 or higher |
| Vaneo | CTEL-Cellular telephone 1 (fixed installation or portable)(D28) | Read Codes | | V1.00.001 or higher |
| Vaneo | CTEL-Cellular telephone 1 (fixed installation or portable)(D28) | Clear Codes | | V1.00.001 or higher |
| Vaneo | UH-Cellular telephone (fixed installation or portable)(D28) | ECU Information | | V1.00.001 or higher |
| Vaneo | UH-Cellular telephone (fixed installation or portable)(D28) | Read Codes | | V1.00.001 or higher |
| Vaneo | UH-Cellular telephone (fixed installation or portable)(D28) | Clear Codes | | V1.00.001 or higher |
| Vaneo | UH-Cellular telephone (fixed installation or portable)(D28) | Live Data | | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | ECU Information | | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | Read Codes | | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | Clear Codes | | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | Live Data | | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | Control unit adaptations | Control module data | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | Control unit adaptations | Settings | V1.00.001 or higher |
| Vaneo | FTC-Front transmission control | Control unit adaptations | Adaptation | V1.00.001 or higher |
| Vaneo | CL-Central locking control unit | ECU Information | | V1.00.001 or higher |

| | | | | |
|----------------------------|--|--------------------------|---|---------------------|
| Vito/Nano 639 (Up to 2008) | OCF-Overhead control panel | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | OCF-Overhead control panel | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | OCF-Overhead control panel | Control unit adaptations | Normalization Routine/Learning process | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | OCF-Overhead control panel | Control unit adaptations | Initialization of system 'ATA/EDW (Anti-Theft Alarm System)' | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EGS-Electronic transmission control | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EGS-Electronic transmission control | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EGS-Electronic transmission control | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EGS-Electronic transmission control | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EGS-Electronic transmission control | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EGS-Electronic transmission control | Control unit adaptations | Definition | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EGS-Electronic transmission control | Control unit adaptations | Important information on the adaptation limit values | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EGS-Electronic transmission control | Control unit adaptations | Important information on the combination possibilities for adaptation end stop values | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EGS-Electronic transmission control | Control unit adaptations | Display and reset of adaptation data | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EGS-Electronic transmission control | Control unit adaptations | Performing adaptation | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EGS-Electronic transmission control | Special Functions | Code manually | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EGS-Electronic transmission control | Special Functions | Coding according to plant data | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ENR-Electronic rear axle level control | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ENR-Electronic rear axle level control | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ENR-Electronic rear axle level control | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ENR-Electronic rear axle level control | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ENR-Electronic rear axle level control | Control unit adaptations | Replace control module. (Only the calibration data are transferred.) | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ENR-Electronic rear axle level control | Control unit adaptations | Level calibration | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Control unit adaptations | Component 'B24/B (Steering Angle Sensor (SAS))': Please calibrate. | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Control unit adaptations | Calibration of the Steering Angle Sensor (SAS) | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Special Functions | Coding/Vehicle length | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Special Functions | Parameterization of hydraulic brake assist (Read only - cannot be changed) | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Special Functions | Parameterization | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Special Functions | Automatic control module replacement | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Special Functions | Coding according to plant data | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Control unit adaptations | Component 'B24/B (Steering angle sensor)': Please calibrate. | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Control unit adaptations | Component 'B24/15 (Yaw rate, lateral and longitudinal acceleration sensor)': Please calibrate. | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Special Functions | Start-off assist | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Special Functions | Trailer Stability Assist (TSA) | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Special Functions | Vehicle weight | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Special Functions | TSH (Radio Remote Control TSH) Stop lamp | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Special Functions | System parameter block 1 | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Special Functions | System parameter block 2 | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Special Functions | Parameterization mode | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESP-Electronic stability program | Special Functions | Engine Start/Stop device | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESM-Electronic selector module | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESM-Electronic selector module | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESM-Electronic selector module | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESM-Electronic selector module | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESM-Electronic selector module | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EZS-Electronic ignition switch | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EZS-Electronic ignition switch | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EZS-Electronic ignition switch | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EZS-Electronic ignition switch | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EZS-Electronic ignition switch | Control unit adaptations | Disable the key or key track. | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EZS-Electronic ignition switch | Control unit adaptations | Disable the key or key track with the workshop key. | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EZS-Electronic ignition switch | Control unit adaptations | Authorize the key or key track once again. | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EZS-Electronic ignition switch | Control unit adaptations | Detach the transport protection. N73 (Electronic Ignition Switch (E15/EZ3) control module) | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EZS-Electronic ignition switch | Control unit adaptations | Detach the transport protection. N26/5 (Electric steering lock) | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EZS-Electronic ignition switch | Control unit adaptations | Personalizing N73 (Electronic Ignition Switch (E15/EZ3) control module) | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EZS-Electronic ignition switch | Control unit adaptations | Personalizing N26/5 (Electric steering lock) | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EZS-Electronic ignition switch | Control unit adaptations | Drive Authorization System (Diagnostic Tools/FBS) (Electronic Ignition Switch (E15/EZ3) ECU Common-rail Diesel Injection): Detach the transport protection. Personalizing. Activating | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EZS-Electronic ignition switch | Control unit adaptations | Program the replacement keys. | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | EZS-Electronic ignition switch | Special Functions | Changeover (ESP 5.7 - ESP 8.1) | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ECU Information | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Control unit adaptations | Learning to the Drive Authorization System (Diagnostic Tools/FBS) | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Control unit adaptations | Setting the main odometer forward and back | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Control unit adaptations | Setting the main odometer forward | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Control unit adaptations | ASSYST settings | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Oil Reset | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Special Functions | Read the coding and change as necessary. | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Special Functions | Coding according to plant data | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Initial startup | Automatic control module replacement | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Initial startup | Manual replacement of control module | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Control unit adaptations | Personalizing | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Control unit adaptations | Setting the main odometer forward | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Control unit adaptations | Resetting the menu settings to manufacturer default settings | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Oil Reset | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | IC-Instrument cluster | Special Functions | Set date and time. | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | REAR AC-Rear air conditioning | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | REAR AC-Rear air conditioning | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | REAR AC-Rear air conditioning | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | REAR AC-Rear air conditioning | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | REAR AC-Rear air conditioning | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | REAR AC-Rear air conditioning | Control unit adaptations | Normalize the component 'A32/2m3 (Rear blending air flap actuator motor)'. | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | AAC-Automatic air conditioning | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | AAC-Automatic air conditioning | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | AAC-Automatic air conditioning | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | AAC-Automatic air conditioning | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | AAC-Automatic air conditioning | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | AAC-Automatic air conditioning | Control unit adaptations | Normalization of the positioning motors | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ME-SFI 2.8-Motor electronics 2.8 | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ME-SFI 2.8-Motor electronics 2.8 | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ME-SFI 2.8-Motor electronics 2.8 | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ME-SFI 2.8-Motor electronics 2.8 | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ME-SFI 2.8-Motor electronics 2.8 | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ME-SFI 2.8-Motor electronics 2.8 | Control unit adaptations | Variant coding | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ME-SFI 2.8-Motor electronics 2.8 | Control unit adaptations | Default initialization | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ME-SFI 2.8-Motor electronics 2.8 | Control unit adaptations | Adaptation | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ME-SFI 2.8-Motor electronics 2.8 | Special Functions | Correction programming | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | UCF-Upper control panel | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | UCF-Upper control panel | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | UCF-Upper control panel | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | UCF-Upper control panel | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | UCF-Upper control panel | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PSM-Parameterizable Special Module | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PSM-Parameterizable Special Module | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PSM-Parameterizable Special Module | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PSM-Parameterizable Special Module | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PSM-Parameterizable Special Module | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PSM-Parameterizable Special Module | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PSM-Parameterizable Special Module | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PSM-Parameterizable Special Module | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PSM-Parameterizable Special Module | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PSM-Parameterizable Special Module | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PTC-Heater booster | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PTC-Heater booster | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PTC-Heater booster | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PTC-Heater booster | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PTC-Heater booster | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PTC-Heater booster | Control unit adaptations | Normalization Routine/Learning process | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PTC-Heater booster | Control unit adaptations | Adapt the obstacle protection. | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | PTC-Heater booster | Control unit adaptations | Coding of the SRSHD (Tilting/Sliding Sunroof) Automatic Operation Function | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | Radio (SOUND series) | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | Radio (SOUND series) | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | Radio (SOUND series) | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | Radio (SOUND series) | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | Radio (SOUND series) | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA passenger-Electric seat adjustment front passenger (with memory) | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA passenger-Electric seat adjustment front passenger (with memory) | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA passenger-Electric seat adjustment front passenger (with memory) | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA passenger-Electric seat adjustment front passenger (with memory) | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA passenger-Electric seat adjustment front passenger (with memory) | Active Test | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA passenger-Electric seat adjustment front passenger (with memory) | Control unit adaptations | Normalization of the forward/back adjustment | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA passenger-Electric seat adjustment front passenger (with memory) | Control unit adaptations | Normalization of the height adjustment at front | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA passenger-Electric seat adjustment front passenger (with memory) | Control unit adaptations | Normalization of the height adjustment at rear | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA passenger-Electric seat adjustment front passenger (with memory) | Control unit adaptations | Normalization of the head restraint adjustment | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA passenger-Electric seat adjustment front passenger (with memory) | Control unit adaptations | Normalization of the backrest adjustment | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA driver-Electric seat adjustment driver (with memory) | ECU Information | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA driver-Electric seat adjustment driver (with memory) | Read Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA driver-Electric seat adjustment driver (with memory) | Clear Codes | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA driver-Electric seat adjustment driver (with memory) | Live Data | | V1.00.001 or higher |
| Vito/Nano 639 (Up to 2008) | ESA driver-Electric seat adjustment driver (with memory) | Active Test | | V1.00.001 or higher |

| | | | | |
|-----------------------------|---|--------------------------|--|---------------------|
| Vito/Niano 639 (As of 2008) | STE-L-ESD [STE] Left electric sliding door | Live Data | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | STE-L-ESD [STE] Left electric sliding door | Active Test | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | STE-L-ESD [STE] Left electric sliding door | Control unit adaptations | Normalization | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | STE-L-ESD [STE] Left electric sliding door | Control unit adaptations | Detection of sliding movement | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | STE-L-ESD [STE] Left electric sliding door | Control unit adaptations | Denormalization | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | STE-R-ESD [STE] Right electric sliding door | ECU Information | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | STE-R-ESD [STE] Right electric sliding door | Read Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | STE-R-ESD [STE] Right electric sliding door | Clear Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | STE-R-ESD [STE] Right electric sliding door | Live Data | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | STE-R-ESD [STE] Right electric sliding door | Active Test | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | STE-R-ESD [STE] Right electric sliding door | Control unit adaptations | Normalization | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | STE-R-ESD [STE] Right electric sliding door | Control unit adaptations | Detection of sliding movement | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | STE-R-ESD [STE] Right electric sliding door | Control unit adaptations | Denormalization | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | TPC-Tire pressure monitor | ECU Information | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | TPC-Tire pressure monitor | Read Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | TPC-Tire pressure monitor | Clear Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | TPC-Tire pressure monitor | Live Data | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | TPC-Tire pressure monitor | Active Test | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | TPC-Tire pressure monitor | Control unit adaptations | Writing of specified pressure values. | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | TPC-Tire pressure monitor | Special Functions | Initial start-up with automatic takeover of settings from the old control module | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | TPC-Tire pressure monitor | Special Functions | Initial start-up with manual settings input for new control module-For example: The previous control module cannot be read any longer. | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | TPC-Tire pressure monitor | Special Functions | Variant coding | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | TPC-Tire pressure monitor | Special Functions | Tire pressure set values | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | DCM-FL-Door control module front left | ECU Information | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | DCM-FL-Door control module front left | Read Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | DCM-FL-Door control module front left | Clear Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | DCM-FL-Door control module front left | Live Data | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | DCM-FL-Door control module front left | Active Test | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | DCM-FL-Door control module front left | Control unit adaptations | Parameterization of N69/1 (Left front door control unit [DCM-LF [TSG-VL]]) Power window | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | DCM-FR-Door control module front right | ECU Information | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | DCM-FR-Door control module front right | Read Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | DCM-FR-Door control module front right | Clear Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | DCM-FR-Door control module front right | Live Data | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | DCM-FR-Door control module front right | Active Test | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | DCM-FR-Door control module front right | Control unit adaptations | Parameterization of N69/2 (Right front door control unit [DCM-RF [TSG-VR]]) Power window | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ECU Information | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | Read Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | Clear Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | Live Data | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | CDW-CD changer | ECU Information | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | CDW-CD changer | Read Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | CDW-CD changer | Clear Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | CDW-CD changer | Live Data | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | RADIO Sound 5 | ECU Information | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | RADIO Sound 5 | Read Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | RADIO Sound 5 | Clear Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | RADIO Sound 5 | Live Data | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | RADIO Sound 5 | ECU Information | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | NAVI-Navigation system (COMMAND_SOUND 50) | Read Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | NAVI-Navigation system (COMMAND_SOUND 50) | Clear Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | NAVI-Navigation system (COMMAND_SOUND 50) | Live Data | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | RADIO Sound 20 | ECU Information | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | RADIO Sound 20 | Read Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | RADIO Sound 20 | Clear Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | RADIO Sound 20 | Live Data | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | AVN-Headlamp range adjustment | ECU Information | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | AVN-Headlamp range adjustment | Read Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | AVN-Headlamp range adjustment | Clear Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | AVN-Headlamp range adjustment | Live Data | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | TEL-Telephone control unit | ECU Information | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | TEL-Telephone control unit | Read Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | TEL-Telephone control unit | Clear Codes | | V1.00.001 or higher |
| Vito/Niano 639 (As of 2008) | TEL-Telephone control unit | Live Data | | V1.00.001 or higher |