VW V01 15 Da	ig Function List (Note:For reference only)
	ig function List (Note.101 feference only)
NOTES: ● This function is supported.	
	, which depends on the actual condition of the vehicle.
O This function is not supported	
▲ This function is the new featu	re in this version.
Vehicle	Model Year
12 - Up/Cross up	2014 - 2017
13 - Scirocco	2009 - 2017
15 - New Bora	2008 -
16 - Jetta	2011 - 2017
17 - Golf Citi	1998 - 2009
18 - Lavida	2008 -
1C - New Beetle	1998 - 2011
1E - Golf Cabrio	1993 - 2002
1F - Eos	2006 - 2017
1G - Golf Jetta II	1989 - 1992
1H - Golf Vento III	1992 - 1999
1J - Bora	1999 - 2005
1J - Golf	1998 - 2006
1K - Golf	2004 - 2009
1K - Jetta	2005 - 2010
1K - Rabbit	2006 - 2009
1T - Touran	2003 - 2017
1V - Golf Cabrio	1997 - 2002
1Y - New Beetle Cab	2003 - 2011
2C - CaddY	2011 - 2015
2D - LT2	1996 - 2006
2E - Crafter LT3	2006 - 2015
2H - Amarok	2010 - 2015
2K - CaddY	2004 - 2010
35 - Passat CC	2009 - 2017
36 - Passat B7	2011 - 2015
3A - Passat B4	1994 - 1997
3B - Passat B5	1997 - 2005
3C - Passat B6	2005 - 2011
3D - Phaeton D1	2003 - 2017
3G - Passat	2015 - 2017
3X - Santana	2001 - 2007
50 - Corrado	- 1995
51 - Golf Cabriolet	2012 - 2017
52 - Golf Plus	2009 - 2014
5C - Beetle	2012 - 2015
5C - Beetle Cab	2013 -
5G - Golf/Jetta VII	2013 - 2017
5K - Golf Jetta VI	2009 - 2014
5M - Golf Plus	2005 - 2009
5N - Tiguan	2008 - 2017
5U - Gol/VoYage/Saveiro	2009 - 2013
5U - Novo Gol/VoYage/Saveiro	2013 - 2017
5W - Gol Par Sav Poi	2006 - 2015
0" 001 1 at 0 av 1 01	2000 2013

5X - Gol Par Sav Poi	1999 - 2017
5Y - Gol Special	1999 - 2005
5Z - Fox/CrossFox/Lupo	2004 - 2017
5Z - SpaceFox/Space	
Cross/Suran/Sportvan	2006 - 2017
60 - Polo	2010 - 2017
61 - Polo	2011 - 2017
6C - Polo	2014 - 2017
6N - Polo	1995 - 2002
6R - Polo	2010 - 2015
6S - Polo Vivo	2010 - 2015
6V - Polo Classic	1996 - 2010
6X - Lupo	1999 - 2006
6Z - XL1	2013 - 2017
70 - Transporter	1991 - 1996
7D - T4 Caravelle	2001 - 2003
7D - Transporter	1996 - 2004
7E - Transporter	2010 - 2015
7F - Transporter/Multivan	2010 - 2015
7H - Transporter	2004 - 2009
7J - Transporter/Multivan	2004 - 2009
7L - Touareg	2003 - 2010
7M - Sharan I	2001 - 2010
7N - Sharan II	2011 - 2017
7P - Touareg	2010 - 2017
7X - Kombi	2006 - 2015
9A - Polo	2003 - 2015
9B - Golf	1999 - 2015
9C - New Beetle	1998 - 2011
9F - Passat B5	
9K - CaddY	1996 - 2003
9M - Jetta IV	1999 - 2015
9N - Polo	2002 - 2010
9V - Polo	2001 - 2003
A3 - Passat	2011 - 2017
A9 - Touareg NAR	2010 - 2011
AA - Up	2012 - 2017
AG - New Beetle NAR	2010
AH - Eos NAR	2010 -
AJ - Golf Jetta VI NAR	2010 - 2014
AL - New Beetle Cab NAR	2010
AM - Golf	2014 - 2017
AN - Passat	2010 -
AT - Beetle Cab NAR	2012 -
AU - Golf	2013 - 2015
AX - Tiguan NAR	2010 -
BA - Golf Variant VII	2014 -
BE - Golf	2013 - 2015
BK - Sagitar	2006 -
BL – Up	2012 - 2017
BP - Touareg NAR	2011 -

BS	- Jetta CHN	2013 -				
BS	- Bora CHN	2013 -				
Sys	stemlist		EcuInfo.	ReadCodes	EraseCode	LiveData
01	Engine Control Module 1		•	•	•	•
02	Transmission Control Module		•	•	•	•
03	Brake Control Module		•	•	•	•
04	Steering Angle Sender		•	•	•	•
05	Kessy		•	•	•	•
06	Seat Adjustment Passenger Side		•	•	•	•
07	Display Control Unit		•	•	•	•
08	Air Conditioning		•	•	•	•
09	Central Electrics		•	•	•	•
0B	Auxiliary Air Heater		•	•	•	•
0C	Rear Axle Steering 2		•	•	•	•
0D	Sliding Door Left		•	•	•	•
0E	Media Player Position 1		•	•	•	•
0F	Radio Tuner - Digital		•	•	•	•
10	Parking Assistance 2		•	•	•	•
11	Engine Control Module 2		•	•	•	•
12	Clutch Control Unit		•	•	•	•
13	Adaptive Cruise Control		•	•	•	•
14	Wheel Dampening Electronics		•	•	•	•
15	Airbag		•	•	•	•
16	Steering Column Electronics		•	•	•	•
17	Dash Board		•	•	•	•
18	Auxiliary Parking Heating		•	•	•	•
19	Gateway		•	•	•	•
1B	Power-Assisted Steering		•	•	•	•
1C	Vehicle Position Detection		•	•	•	•
1D	Driver Identification		•	•	•	•
1E	Media Player Position 2		•	•	•	•
1F	Radio Satellite		•	•	•	•
20	High Beam Assistance		•	•	•	•
21	Battery Energy Control Module 2		•	•	•	•
22	4WD Electronics		•	•	•	•
23	Brake Boost		•	•	•	•
24	Drive Slip Control		•	•	•	•
25	Immobilizer		•	•	•	•
26	Electric Roof Control		•	•	•	•
27	Display Control Unit Rear		•	•	•	•
-	Climate Control Unit Rear		•	•	•	•
29	Light Control Left		•	•	•	•
	Steer Column Locking		•	•	•	•
	Voice Amplifier		•	•	•	•
-	Media Player Position 3		•	•	•	•
-	TV Tuner - Digital		•	•	•	•
-	Special Function 2		•	•	•	•
	Engine Electronics Conjunction		•	•	•	•
32	Locking Electroniscs		•	•	•	•
34	Self Adjustment Suspension		•	•	•	•
35	Central Locking Control Module		•	•	•	●

36 Seat Adjustment Driver Side			•	
37 Navigation	•	•	•	
38 Roof Electronics		•	•	
39 Light Control Right	•	•	•	
3A Special Vehicle Assistant	•	•	•	•
3B Sensor Electronics	•	•	•	•
3C Lane Change Assistance System				
3D Special Function	•	•	•	•
3E Media Player Position 4	•	•	•	•
40 Air Conditioning Compressor	•	•	•	•
41 Diesel Pump Electronics	•	•	•	•
42 Driver-Door Electronics	•	•	•	•
43 Braker Boost Assistance				
44 Steering Assistance	•	•	•	•
45 Interior Monitoring	•	•	•	•
46 Central Control Module	•	•	•	•
47 Sound System	•	•	•	•
48 Seat Adjustment Rear Driver Side	•	•	•	•
49 Automatic Lighting Switch	•	•	•	•
4B Multifunction Module	•	•	•	•
4C Tyre Pressure Monitor II	•	•	•	•
4E Control Head Rear Right	•	•	•	•
4F Central Electronics II	•	•	•	•
51 Drive Motor Control Module	•	•	•	•
52 Passenger-Door Electronics	•	•	•	•
53 Parking Brake	•	•	•	•
54 Rear Spoiler	•	•	•	•
55 Headlight Range Control	•	•	•	•
56 Radio	•	•	•	•
57 TV-Tuner	•	•	•	•
58 Auxiliary Fuel Tank	•	•	•	•
59 Towing Protection	•	•	•	•
5B Seat Adjustment Rear Passenger Side	•	•	•	•
5C Lane Keeping Assistance System	•	•	•	•
5D Operation	•	•	•	•
5E Control Head Left Rear	•	•	•	•
5F Information Control Unit 1	•	•	•	•
61 Battery Regulation	•	•	•	•
62 Door Electronics Left Rear	•	•	•	•
63 Entry Assistance Driver Side	●	●	●	•
64 Stabilizers	●	●	●	•
65 Tyre Pressure Monitoring I	●	●	●	●
66 Seat/Mirror Adjustment	●	●	●	•
67 Voice Control	•	•	•	•
68 Wiper Control Unit	●	●	●	•
69 Trailer Function	•	●	●	•
6B Aerodynamics Control Module	•	•	•	•
6C Camera System Rear View	●	•	•	•
6D Electronic Equipment of Trunk Lid	•	•	●	•
6E Display Control Roof	•	•	•	•
6F Central Control Module II	•	•	•	•

22 Door: Fleetronics Right Rear       ••••••••••••••••••••••••••••••••••••	71 Battery Charger		•	•	
23 Entry Assistance Passenger Side <ul> <li>A Vehicle Control System</li> <li>Control Unit 2</li> <li>Control Unit 2</li> <li>Control Unit 2</li> <li>Control Module</li> <li>Control Module</li> <li>Control Module</li> <li>Control Module</li> <li>Control Module</li> <li>Control System</li> <li>Control Module IT3</li> <li>Control System</li> <li>Control System</li> <li>Contrestron System</li> <li>Control S</li></ul>					•
24 Vehicle Control System       •       •         75 Telematics Communication Unit       •       •         76 Parking Assistance       •       •         77 Telephone       •       •         78 Sliding Door       •       •         70 Auxiliary Heater       •       •         71 Information Control Unit 2       •       •         81 Geart Shift Control Module       •       •         82 Head Up Display       •       •         85 On Beard-Camera       •       •         86 Miti Contour Seat Driver Side       •       •         87 Multi Contour Seat Passenger Side       •       •         88 Multi Contour Seat Rear Passenger Side       •       •         80 Multi Contour Seat Rear Passenger Side       •       •         80 Matti Contour Seat Rear Passenger Side       •       •         80 Matti Contour Seat Rear Passenger Side       •       •         80 Multi Contour Seat Rear Passenger Side       •       •         81 Marge Processing Electronics       •       •       •         82 Inange Processing Electronics IT3       •       •       •         91 Engine Control Module LT3       •       •       • <t< td=""><td></td><td>•</td><td>•</td><td>•</td><td>•</td></t<>		•	•	•	•
75 Telematics Communication Unit       •       •         76 Parking Assistance       •       •         77 Telephone       •       •         78 Sliding Door       •       •         78 Sliding Door       •       •         78 Dash Board Display Unit       •       •         76 Thromation Control Unit 2       •       •         81 Genr Shift Control Module       •       •         82 Head Up Display       •       •         84 Night Vision       •       •         85 On Board-Cammera       •       •         86 Matic Contour Seat Passenger Side       •       •         87 Mili Contour Seat Passenger Side       •       •         86 Maptic Consest Rear PassengerSide       •       •         86 Maptic Consessing Electronics       •       •         87 Elmage Processing Electronics       •       •         88 Limage Processing Electronics       •       •         80 I Fince Control. Would LT3       •       •         81 Ender Processing Electronics       •       •         81 Isope Processing Electronics       •       •         82 Transpission Electronics LT3       •       •         83 Immobiliz		•	•	•	•
26 Parking Assistance       •       •         27 Telephone       •       •         28 Sliding Door       •       •         20 Auxiliary Heater       •       •         27 Information Control Unit 2       •       •         81 Gear Shift Control Module       •       •         82 Iead Up Display       •       •         84 Night Vision       •       •         85 On Board-Camera       •       •         88 Muiti Contour Seat Driver Side       •       •         88 Muiti Contour Seat Rear Driver Side       •       •         88 Muiti Contour Seat Rear Driver Side       •       •         80 Malti Contour Seat Rear Driver Side       •       •         80 Muit Contour Seat Rear Passenger Side       •       •         80 Muit Contour Seat Rear Passenger Side       •       •         80 Muit Contour Seat Rear Passenger Side       •       •         90 Protensioner Front Left       •       •       •         91 Engine Control Moulle LT3       •       •       •         92 Transmission Electronics LT3       •       •       •         93 Immobilizer LT3       •       •       •         94 Airbag LT3		•	•	•	•
17 Telephone       •       •       •         78 Sliding Door       •       •       •         70 Auxiliary Heater       •       •       •         71 Tormation Control Unit 2       •       •       •         81 Gear Shift Control Molule       •       •       •         82 Head Up Display       •       •       •       •         83 On Board-Camera       •       •       •       •         85 On Board-Camera       •       •       •       •         85 Muiti Contour Seat Passenger Side       •       •       •       •         86 Adaptive Cruise Control 2       •       •       •       •       •         80 Muiti Contour Seat Rear Passenger Side       •		•		•	•
28 Sliding Door       •		•	•	•	•
7D Auxiliary Heater       •       •       •         7E hash Board Display Unit       •       •       •         7F Information Control Unit 2       •       •       •         81 Gear Shift Control Module       •       •       •         82 Head Up Display       •       •       •         84 Night Vision       •       •       •         85 On Board-Cammera       •       •       •         85 Muiti Contour Seat Passenger Side       •       •       •         88 Muiti Contour Seat Rear Driver Side       •       •       •         88 Adaptive Cruise Control 2       •       •       •       •         80 Muiti Contour Seat Rear Passenger Side       •       •       •       •       •         81 Image Processing Electronics       •		•	•	•	•
7E Dash Board Display Unit       •       •         7IF Information Control Unit 2       •       •         8I Gear Shift Control Module       •       •         81 Might Vision       •       •         85 On Board-Cammera       •       •         88 Milit Contour Seat Driver Side       •       •         89 Multi Contour Seat Passenger Side       •       •         89 Adaptive Cruise Control 2       •       •         80 Matiti Contour Seat Rar Passenger Side       •       •         80 Multi Contour Seat Rar Passenger Side       •       •         80 Multi Contour Seat Rar Passenger Side       •       •         81 Emage Processing Electronics       •       •       •         82 Emage Processing Electronics       •       •       •       •         90 Pretensioner Front Right       •       •       •       •       •         91 Engine Control Mudle LT3       • </td <td></td> <td>•</td> <td>•</td> <td>•</td> <td>•</td>		•	•	•	•
7F Information Control Unit 2   8I Gear Shift Control Module   82 Head Up Display   84 Night Vision   85 On Board-Cammera   88 Muiti Contour Seat Driver Side   89 Muiti Contour Seat Passenger Side   80 Muiti Contour Seat Rear Driver Side   81 Mater Schwarz   82 Badaptive Cruise Control 2   83 Badaptive Cruise Control 2   84 E Hange Processing Electronics   85 Image Processing Electronics   86 Protensioner Front Left   90 Pretensioner Front Right   91 Engine Control Module LT3   92 Transmission Electronics LT3   93 Immobilizer LT3   94 Airbag LT3   95 Electronic Stability Program LT3   96 Instruments Cluster LT3   97 Tackograph LT3   98 Tire Pressure Monitoring LT3   99 Electrical Ignition/Starter Switch LT3   90 Arbus LT3   91 Boriver's Door Electronics LT3   92 Transmi Statility Program LT3   94 Arbus LT3   95 Electronics LT3   96 Instruments Cluster LT3   97 Tackograph LT3   98 Driver's Door Electronics LT3   99 Arbus LT3   90 Arbus LT3   91 Engine Control LT3   92 Transmi System Electronics LT3   94 Arbus LT3   95 Treperser Monitoring LT3   96 Treperser Monitoring LT3   97 Tackograph LT3   98 Arbus LT3		•	•	•	•
81 Gear Shift Control Module       •         82 Head Up Display       •         84 Night Vision       •         85 On Board-Cammera       •         88 Muiti Contour Seat Driver Side       •         89 Multi Contour Seat Rear Driver Side       •         88 Adaptive Cruise Control 2       •         86 Adaptive Cruise Control 2       •         87 Battery Energy Control Module       •         80 Muiti Contour Seat Rear Passenger Side       •         81 Fretensioner Front Right       •         90 Pretensioner Front Right       •         91 Engine Control Moudle LT3       •         92 Transmission Electronics LT3       •         93 Immobilizer LT3       •         94 Airbag LT3       •         95 Electronic Stability Program LT3       •         96 Instruments Cluster LT3       •         97 Tachograph LT3       •         98 Tire Pressure Monitoring LT3       •         99 Electrical Ignition/Starter Switch LT3       •         90 Auxiliary Heater (Fuel)LT3       •		•	•	•	•
82 Head Up Display       •       •         84 Night Vision       •       •         85 On Board-Cammera       •       •         88 Muiti Contour Seat Driver Side       •       •         89 Multi Contour Seat Rar Driver Side       •       •         88 Muiti Contour Seat Rar Driver Side       •       •         88 Matri Contour Seat Rar Driver Side       •       •         88 Matri Contour Seat Rar Driver Side       •       •         89 Multi Contour Seat Rar Driver Side       •       •         80 Muiti Contour Seat Rar Passenger Side       •       •         80 Freetensioner Front Right       •       •       •         90 Pretensioner Front Right       •       •       •         91 Engine Control Modele LT3       •       •       •         92 Transmission Electronics LT3       •       •       •         93 Inmobilizer LT3       •       •       •       •         94 Airbag LT3       •       •       •       •         95 Electronic Stability Program LT3       •       •       •       •         96 Instruments Cluster LT3       •       •       •       •       •         96 Interuments Cluster LT3		•	•	•	•
84 Night Vision       •       •         85 On Board-Cammera       •       •         88 Muiti Contour Seat Driver Side       •       •         89 Multi Contour Seat Rear Driver Side       •       •         80 Multi Contour Seat Rear Driver Side       •       •         80 Adaptive Cruise Control 2       •       •       •         80 Multi Contour Seat Rear Passenger Side       •       •       •         80 Multi Contour Seat Rear Passenger Side       •       •       •       •         80 Multi Contour Seat Rear Passenger Side       •       <		•	•	•	•
85 On Board-Cammera       •       •         88 Muiti Contour Seat Driver Side       •       •         89 Multi Contour Seat Rear Driver Side       •       •         80 Muiti Contour Seat Rear Driver Side       •       •         80 Muiti Contour Seat Rear Driver Side       •       •         80 Muiti Contour Seat Rear Passenger Side       •       •         80 Muiti Contour Seat Rear Passenger Side       •       •         80 Muiti Contour Seat Rear Passenger Side       •       •         81 Emage Processing Electronics       •       •         85 Fretensioner Front Left       •       •       •         90 Pretensioner Front Right       •       •       •       •         91 Engine Control Moudle LT3       •       •       •       •       •         92 Transmission Electronics LT3       •		•	•	•	•
88 Muiti Contour Seat Passenger Side       •       •         89 Multi Contour Seat Passenger Side       •       •         88 Adaptive Cruise Control 2       •       •         88 Adaptive Cruise Control Nodule       •       •         80 Muiti Contour Seat Rear Passenger Side       •       •         80 Muiti Contour Seat Rear Passenger Side       •       •         80 Muiti Contour Seat Rear Passenger Side       •       •         81 Maper Drocessing Electronics       •       •         82 Transmission Electronics LT3       •       •         91 Engine Control Moulle LT3       •       •         92 Transmission Electronics LT3       •       •         93 Immobilizer LT3       •       •       •         94 Airbag LT3       •       •       •         95 Electronic Stability Program LT3       •       •       •         96 Instruments Cluster LT3       •       •       •       •         98 Tire Pressure Monitoring LT3       •       •       •       •         98 Driver's Door Electronics LT3       •       •       •       •         90 Auxiliary Heater (Fuel)LT3       •       •       •       •       •         91 Auxil		•	•	•	•
89 Multi Contour Seat Passenger Side   8A Muiti Contour Seat Rear Driver Side   8B Adaptive Cruise Control 2   8C Battery Energy Control Module   8D Muiti Contour Seat Rear Passenger Side   8D Muiti Contour Seat Rear Passenger Side   8E Image Processing Electronics   8F Pretensioner Front Left   90 Pretensioner Front Right   91 Engine Control Module LT3   92 Transmission Electronics LT3   93 Immobilizer LT3   94 Airbag LT3   95 Electronic Stability Program LT3   96 Instruments Cluster LT3   97 Tachograph LT3   98 Tire Pressure Monitoring LT3   99 Electrical Ignition/Starter Switch LT3   90 Axiliary Heater(Fuel)LT3   90 Auxiliary Heater(Electric)LT3   91 Auxiliary Heater(Electric)LT3   92 Auxiliary Heater(Electric)LT3   94 Airbag LT3   95 Additional Heater, Water LT3   96 Additional Heater, Water LT3   97 Advalidional Heater, System   96 Adatio 'Audio 5' LT3   97 Actonore Strast   98 Advalidional Heater, Water LT3   99 Electronic Strast   90 Availiary Heater(Blectric)LT3   91 Advalidional Heater, Water LT3   92 Actuator for Structure-Borne Sound   93 Tineothener LT3   94 Airbag LT3   95 Additional Heater, Bastance System   96 Alcuator for Structure-Borne Sound   97 Alcuator for Structure-Borne Sound   98 Alcuator for Structure-Borne Sound   99 Activator for Structure-Borne Sound   90 Acuator for		•	•	•	•
8A Muiti Contour Seat Rear Driver Side       •       •         8B Adaptive Cruise Control 2       •       •         8C Battery Energy Control Module       •       •         8D Muiti Contour Seat Rear Passenger Side       •       •         8D Muiti Contour Seat Rear Passenger Side       •       •         8D Muiti Contour Seat Rear Passenger Side       •       •         8D Muiti Contour Seat Rear Passenger Side       •       •         9D Pretensioner Front Left       •       •       •         90 Pretensioner Front Right       •       •       •         91 Engine Control Moudle LT3       •       •       •         92 Transmission Electronics LT3       •       •       •         93 Immobilizer LT3       •       •       •       •         94 Airbag LT3       •       •       •       •       •         95 Electronic Stability Program LT3       •       •       •       •       •       •         97 Tachograph LT3       • <t< td=""><td></td><td>•</td><td>•</td><td>•</td><td>•</td></t<>		•	•	•	•
8B Adaptive Cruise Control 2       •       •         8C Battery Energy Control Module       •       •         8D Muiti Contour Seat Rear Passenger Side       •       •         8E Image Processing Electronics       •       •         8F Pretensioner Front Left       •       •       •         90 Pretensioner Front Left       •       •       •       •         91 Engine Control Moudle LT3       •       •       •       •         92 Transmission Electronics LT3       •       •       •       •         93 Immobilizer LT3       •       •       •       •       •         94 Airbag LT3       •       •       •       •       •       •         95 Electronic Stability Program LT3       •       <		•	•	•	•
8C Battery Energy Control Module   8D Muiti Contour Seat Rear Passenger Side   8E Inage Processing Electronics   8F Pretensioner Front Left   90 Pretensioner Front Right   91 Engine Control Moudle LT3   92 Transmission Electronics LT3   93 Immobilizer LT3   94 Airbag LT3   95 Electronic Stability Program LT3   96 Instruments Cluster LT3   97 Tachograph LT3   98 Tire Pressure Monitoring LT3   99 Electronics LT3   90 Remote Control LT3   91 Engine Control LT3   92 Auxiliary Heater (Fuel)LT3   95 Additional Heater, Water LT3   96 Addito 'Audio 5' LT3   97 Additional Heater, Water LT3   98 Aringater LT3   97 Additional Heater, Water LT3   98 Anitary Heater (Electric)LT3   99 Availiary Heater (Sectro)LT3   90 Availiary Heater (Sectro)LT3   91 An vigation LT3   92 Auxiliary Heater (Sectro)LT3   93 An Navigation LT3   94 Airbag LT3   95 Electronics LT3   96 Additional Heater, Water LT3   97 Additional Heater, Water LT3   98 Driver's Soor Electronics LT3   99 Auxiliary Heater (Sectro)LT3   91 Auxiliary Heater (Sectro)LT3   92 Auxiliary Heater (Sectro)LT3   93 Altional Heater, Water LT3   94 Airbag LT3   95 Additional Heater, Water LT3   96 Additional Heater, Water LT3   97 Additional Heater, Water LT3   98 Altional Heater, Water LT3   99 Additional Heater, Water LT3<		•	•	•	•
8D Muiti Contour Seat Rear Passenger Side <ul> <li>E Image Processing Electronics</li> <li>E Image Processing Electronics</li> <li>Fretensioner Front Left</li> <li>Fretensioner Front Right</li> <li>Fretensioner Right</li> <li>Fretensure Monitoring LT3</li> <li>Fretensure Right</li> <li>Fretensure Monitoring LT3</li> <li>Fretensure Right</li> <li>Fretensure Right</li> <li>Fretensure Right</li> <li>Fretensure Right</li> <li>Fretensure Right</li> <li>Fretensure Right</li></ul>		•	•	•	•
8E Image Processing Electronics       •       •       •         8F Pretensioner Front Left       •       •       •         90 Pretensioner Front Right       •       •       •         91 Engine Control Moudle LT3       •       •       •         92 Transmission Electronics LT3       •       •       •         93 Immobilizer LT3       •       •       •       •         94 Airbag LT3       •       •       •       •       •         95 Electronic Stability Program LT3       • <t< td=""><td></td><td>•</td><td>•</td><td>•</td><td>•</td></t<>		•	•	•	•
8F Pretensioner Front Left       •       •       •         90 Pretensioner Front Right       •       •       •         91 Engine Control Moudle LT3       •       •       •         92 Transmission Electronics LT3       •       •       •         93 Immobilizer LT3       •       •       •       •         94 Airbag LT3       •       •       •       •       •         95 Electronic Stability Program LT3       •		•	-	•	•
90 Pretensioner Front Right   91 Engine Control Moudle LT3   92 Transmission Electronics LT3   93 Immobilizer LT3   94 Airbag LT3   95 Electronic Stability Program LT3   96 Instruments Cluster LT3   97 Tachograph LT3   98 Tire Pressure Monitoring LT3   99 Electrical Ignition/Starter Switch LT3   90 A Remote Control LT3   91 Aviliary Heater (Fuel)LT3   92 Aviliary Heater (Fuel)LT3   95 Eleptonic Statistance System   96 Addic 'Audio 5' LT3   97 Adolo Control Unit   98 Tire Press Driver Assistance System   99 Aviliary Interface   90 Avalator for Structure-Borne Sound   91 Ac Reador Control Module   92 Ac Reador Control Head (Roof Control Head) LT3		•	-	•	•
91 Engine Control Moudle LT3   92 Transmission Electronics LT3   93 Immobilizer LT3   94 Airbag LT3   95 Electronic Stability Program LT3   96 Instruments Cluster LT3   97 Tachograph LT3   98 Tire Pressure Monitoring LT3   99 Electrical Ignition/Starter Switch LT3   90 A Remote Control LT3   90 B Driver's Door Electronics LT3   90 Auxiliary Heater(Fuel)LT3   91 Auxiliary Heater(Electric)LT3   95 Additional Heater, Water LT3   96 Additional Heater, Water LT3   97 Additional Heater, System   96 Addition LT3   97 Addition LT3   98 Ariver Assistance System   96 Additor for Structure-Borne Sound   97 Ackuator for Structure-Borne Sound   98 Ackuator Control Module   99 Ackuator Control Module   90 Auxilo Systems   91 And Systems   92 Alexandre Control Head (Roof Control Head) LT3		•	•	•	•
92 Transmission Electronics LT3   93 Immobilizer LT3   94 Airbag LT3   95 Electronic Stability Program LT3   96 Instruments Cluster LT3   97 Tachograph LT3   98 Tire Pressure Monitoring LT3   99 Electrical Ignition/Starter Switch LT3   90 A Remote Control LT3   90 Anxiliary Heater (Fuel)LT3   90 Auxiliary Heater (Electric)LT3   97 Additional Heater, Water LT3   97 Additional Heater, Water LT3   97 Additional T3   98 Tire Pressure Monitoring LT3   99 Electronics LT3   90 Auxiliary Heater (Electric)LT3   91 Auxiliary Heater (Electric)LT3   92 Auxiliary Heater (Subject Control LT3   93 And Auxiliary Heater (Electric)LT3   94 Airbag LT3   95 Additional Heater, Water LT3   96 Additional Heater, Water LT3   97 Additional Heater, Water LT3   98 Auxiliary Heater (Electric)LT3   99 Electronics LT3   90 Auxiliary Heater (Electric)LT3   91 Auxiliary Heater (Electric)LT3   92 Electronics LT3   93 Auxiliary Heater (Electric)LT3   94 Auxiliary Heater (Electric)LT3   95 Additional Heater, Water LT3   96 Additional Heater, Water LT3   97 Alectronics LT3   98 Auxiliary Heater (Electric)LT3   99 Electronics LT3   99 Electronics LT3   90 Electronics LT3   91 Auxiliary Heater (Electric)LT3   92 Auxiliary Heater (Electric)LT3   93 At the Auxiliary Heater (Electric)LT3   94 At the Auxiliary Heater		•	•	•	•
93 Immobilizer LT3       •       •       •         94 Airbag LT3       •       •       •         95 Electronic Stability Program LT3       •       •       •         96 Instruments Cluster LT3       •       •       •       •         97 Tachograph LT3       •       •       •       •       •         98 Tire Pressure Monitoring LT3       •       •       •       •       •       •         98 Electrical Ignition/Starter Switch LT3       •		•	•	•	•
94 Airbag LT3       •       •       •         95 Electronic Stability Program LT3       •       •       •         96 Instruments Cluster LT3       •       •       •         97 Tachograph LT3       •       •       •       •         98 Tire Pressure Monitoring LT3       •       •       •       •         98 Tire Pressure Monitoring LT3       •       •       •       •         99 Electrical Ignition/Starter Switch LT3       •       •       •       •         90 Aremote Control LT3       •       •       •       •       •         90 Aviliary Heater (Fuel)LT3       •		•	•	•	•
95 Electronic Stability Program LT3   96 Instruments Cluster LT3   97 Tachograph LT3   98 Tire Pressure Monitoring LT3   99 Electrical Ignition/Starter Switch LT3   99 Electrical Ignition/Starter Switch LT3   90 A Remote Control LT3   91 Driver's Door Electronics LT3   92 A/C Electronics LT3   90 Auxiliary Heater (Fuel)LT3   91 Auxiliary Heater (Electric)LT3   92 Additional Heater, Water LT3   94 Remote LT3   95 Additional Heater, Water LT3   96 Andic 'Audio 5' LT3   97 Tachograph LT3   98 And Changer LT3   99 Auxiliary Heater (Fuel)LT3   99 Auxiliary Heater (Electric)LT3   90 Auxiliary Heater (Electric)LT3   91 Auxiliary Heater (Electric)LT3   92 Auxiliary Heater (Electric)LT3   93 A Remote Control Ult3   94 And Audio 5' LT3   95 Front Sensors Driver Assistance System   96 Alicrophone Control Unit   97 Actuator for Structure-Borne Sound   98 Actuator for Structure-Borne Sound   99 Actuator for Structure-Borne Sound   90 Ac Reductant Control Module   90 Ac Reductant Control Head (Roof Control Head) LT3		•	•	•	•
96 Instruments Cluster LT3   97 Tachograph LT3   98 Tire Pressure Monitoring LT3   99 Electrical Ignition/Starter Switch LT3   99 A Remote Control LT3   90 A Remote Control LT3   90 Driver's Door Electronics LT3   90 Auxiliary Heater (Fuel)LT3   90 Auxiliary Heater (Electric)LT3   91 Additional Heater, Water LT3   92 Additional Heater, Water LT3   93 Talephone LT3   94 C C C Changer LT3   95 Front Sensors Driver Assistance System   96 Microphone Control Unit   97 Aduator for Structure-Borne Sound   98 Auxil Control Module   99 Actuator for Structure-Borne Sound   90 Rocof Display/Control Head (Roof Control Head) LT3		•	•	•	•
98 Tire Pressure Monitoring LT3       •       •       •         99 Electrical Ignition/Starter Switch LT3       •       •       •         9A Remote Control LT3       •       •       •       •         9B Driver's Door Electronics LT3       •       •       •       •       •         9C A/C Electronics LT3       •       •       •       •       •       •       •         9D Auxiliary Heater (Fuel)LT3       • <td< td=""><td></td><td>•</td><td>•</td><td>•</td><td>•</td></td<>		•	•	•	•
98 Tire Pressure Monitoring LT3       •       •       •         99 Electrical Ignition/Starter Switch LT3       •       •       •         9A Remote Control LT3       •       •       •       •         9B Driver's Door Electronics LT3       •       •       •       •       •         9C A/C Electronics LT3       •       •       •       •       •       •       •         9D Auxiliary Heater (Fuel)LT3       • <td< td=""><td></td><td>•</td><td>•</td><td>•</td><td>•</td></td<>		•	•	•	•
99 Electrical Ignition/Starter Switch LT3•••9A Remote Control LT3••••9B Driver's Door Electronics LT3••••9C A/C Electronics LT3••••9D Auxiliary Heater(Fuel)LT3••••9E Auxiliary Heater(Electric)LT3••••9F Additional Heater, Water LT3••••A0 Radio 'Audio 5' LT3••••A1 Navigation LT3••••A2 CD Changer LT3••••A5 Front Sensors Driver Assistance System•••A6 Microphone Control Unit••••A7 Infotainment Interface••••A9 Actuator for Structure-Borne Sound••••AD Sensors Brake Systems••••B0 Roof Display/Control Head (Roof Control Head) LT3••••B0 Roof Display/Control Head (Roof Control Head) LT3••••		•	•	•	•
9A Remote Control LT3••••9B Driver's Door Electronics LT3••••9C A/C Electronics LT3••••9D Auxiliary Heater(Fuel)LT3••••9E Auxiliary Heater(Electric)LT3••••9F Additional Heater, Water LT3••••A0 Radio 'Audio 5' LT3••••A1 Navigation LT3••••A2 CD Changer LT3••••A3 Telephone LT3••••A6 Microphone Control Unit••••A7 Infotainment Interface••••A9 Actuator for Structure-Borne Sound••••AD Sensors Brake Systems••••B0 Roof Display/Control Head (Roof Control Head) LT3•••B0 Roof Display/Control Head (Roof Control Head) LT3•••		•	•	•	•
9C A/C Electronics LT3••••9D Auxiliary Heater (Fuel) LT3••••9E Auxiliary Heater (Electric) LT3••••9F Additional Heater, Water LT3••••A0 Radio 'Audio 5' LT3••••A1 Navigation LT3••••A2 CD Changer LT3••••A3 Telephone LT3••••A5 Front Sensors Driver Assistance System•••A6 Microphone Control Unit••••A7 Infotainment Interface••••A9 Actuator for Structure-Borne Sound••••AD Sensors Brake Systems••••B0 Roof Display/Control Head (Roof Control Head) LT3••••		•	•	•	•
9D Auxiliary Heater (Fuel) LT3••••9E Auxiliary Heater (Electric) LT3••••9F Additional Heater, Water LT3••••A0 Radio 'Audio 5' LT3••••A1 Navigation LT3••••A2 CD Changer LT3••••A3 Telephone LT3••••A5 Front Sensors Driver Assistance System•••A6 Microphone Control Unit••••A7 Infotainment Interface••••A9 Actuator for Structure-Borne Sound••••AD Sensors Brake Systems••••B0 Roof Display/Control Head (Roof Control Head) LT3•• <td>9B Driver's Door Electronics LT3</td> <td>•</td> <td>•</td> <td>•</td> <td>•</td>	9B Driver's Door Electronics LT3	•	•	•	•
9E Auxiliary Heater (Electric) LT3•••9F Additional Heater, Water LT3•••A0 Radio 'Audio 5' LT3•••A1 Navigation LT3•••A2 CD Changer LT3•••A3 Telephone LT3•••A5 Front Sensors Driver Assistance System••A6 Microphone Control Unit•••A7 Infotainment Interface•••A9 Actuator for Structure-Borne Sound•••AD Sensors Brake Systems•••B0 Roof Display/Control Head (Roof Control Head) LT3•••	9C A/C Electronics LT3	•	•	•	•
9F Additional Heater, Water LT3••••A0 Radio 'Audio 5' LT3••••A1 Navigation LT3••••A2 CD Changer LT3••••A3 Telephone LT3••••A5 Front Sensors Driver Assistance System•••A6 Microphone Control Unit•••A7 Infotainment Interface•••A9 Actuator for Structure-Borne Sound•••AC Reductant Control Module•••AD Sensors Brake Systems•••B0 Roof Display/Control Head (Roof Control Head) LT3•••	9D Auxiliary Heater(Fuel)LT3	•	•	•	•
AO Radio 'Audio 5' LT3Image: Constraint of the second		•	•	•	•
A1 Navigation LT3••••A2 CD Changer LT3••••A3 Telephone LT3••••A5 Front Sensors Driver Assistance System•••A6 Microphone Control Unit•••A6 Microphone Control Unit•••A7 Infotainment Interface•••A9 Actuator for Structure-Borne Sound•••AC Reductant Control Module•••AD Sensors Brake Systems•••B0 Roof Display/Control Head (Roof Control Head) LT3•••	9F Additional Heater, Water LT3	•	•	•	•
A2 CD Changer LT3••••A3 Telephone LT3•••••A5 Front Sensors Driver Assistance System••••A6 Microphone Control Unit••••A7 Infotainment Interface••••A9 Actuator for Structure-Borne Sound••••AC Reductant Control Module••••AD Sensors Brake Systems••••B0 Roof Display/Control Head (Roof Control Head) LT3•••	AO Radio 'Audio 5' LT3	•	•	•	•
A3 Telephone LT3••••A5 Front Sensors Driver Assistance System••••A6 Microphone Control Unit••••A7 Infotainment Interface••••A9 Actuator for Structure-Borne Sound••••AC Reductant Control Module••••AD Sensors Brake Systems••••B0 Roof Display/Control Head (Roof Control Head) LT3•••	A1 Navigation LT3	•	•	•	•
A5 Front Sensors Driver Assistance System•••A6 Microphone Control Unit•••A7 Infotainment Interface•••A9 Actuator for Structure-Borne Sound•••AC Reductant Control Module•••AD Sensors Brake Systems•••B0 Roof Display/Control Head (Roof Control Head) LT3•••	A2 CD Changer LT3	•	•	•	•
A6 Microphone Control Unit••••A7 Infotainment Interface••••A9 Actuator for Structure-Borne Sound••••AC Reductant Control Module••••AD Sensors Brake Systems••••B0 Roof Display/Control Head (Roof Control Head) LT3••••	A3 Telephone LT3	•	•	•	•
A7 Infotainment Interface•••A9 Actuator for Structure-Borne Sound•••AC Reductant Control Module•••AD Sensors Brake Systems•••B0 Roof Display/Control Head (Roof Control Head) LT3•••	A5 Front Sensors Driver Assistance System	•	•	•	•
A7 Infotainment Interface••••A9 Actuator for Structure-Borne Sound••••AC Reductant Control Module••••AD Sensors Brake Systems••••B0 Roof Display/Control Head (Roof Control Head) LT3••••		•	•	•	•
AC Reductant Control Module••••AD Sensors Brake Systems••••B0 Roof Display/Control Head (Roof Control Head) LT3••••	A7 Infotainment Interface	•	•	•	•
AD Sensors Brake Systems•••B0 Roof Display/Control Head (Roof Control Head) LT3•••	A9 Actuator for Structure-Borne Sound	•	•	•	•
BO Roof Display/Control Head (Roof Control Head) LT3 • • • •	AC Reductant Control Module	•	•	•	•
BO Roof Display/Control Head (Roof Control Head) LT3 • • • •	AD Sensors Brake Systems	•	•	•	•
B1 Upper Operating Field LT3 $ullet$		•	•	•	•
	B1 Upper Operating Field LT3	•	•	•	•

B2 Parking Aid LT3	•	•	•	
B3 Trailer Function LT3	•	•	•	•
B4 Vehicle Electrical System Control Module LT3	•			•
B5 Programmable Special Module LT3	•	•	•	•
B6 Steering Column Jacket Switch Module LT3	•		•	•
B7 Access Startsystem Interface	•	•	•	$\bullet$
B8 Electronic Roof Control 2	•	•	•	•
B9 Auxiliary Display Conrol Unit	•	•	•	•
BA Assembly Mounting	•	•	•	•
BB Door Electronics Rear Driver Side	•	$\bullet$	•	•
BC Door Electronics Rear Passenger Side	•	•	•	•
BD High Voltage Battery Charge Management	•	•	•	•
BE Sliding Door Rear Left	•	•	•	•
BF Sliding Door Right	•	•	•	•
CO Actuator For Exterior Noise	•	•	•	•
C1 Battery regulation LT3	•	$\bullet$	•	•
C2 Transmission Control Module 2	$\bullet$	•	•	ullet
C4 DC/DC Converter Control Module	•	•	•	•
C5 Thermal Management		•	•	•
C6 Battery Charger Control Module			•	•
C7 Pedestrian Protection	•	•	•	•
CB Rear Axle Steering	•	•		
DO Front Axle Lift System	•	$\bullet$	ullet	•